

INSTRUCTIONS FOR THE GUIDANCE OF SURVEYORS ON

LIFE SAVING APPLIANCES

MSIS27 CHAPTER 10

Rev 09.21



PREFACE

- 0.1 These Marine Survey Instructions for the Guidance of Surveyors (MSIS) are not legal requirements in themselves. They may refer to statutory requirements elsewhere. They do represent the MCA policy for MCA surveyors to follow.
- 0.2 If for reasons of practicality, for instance, these cannot be followed then the surveyor must seek at least an equivalent arrangement, based on information from the owner/operator. Whenever possible guidance should be sought from either Principal Consultant Surveyors or Survey Operation Branch, in order to maintain consistency between Marine Offices.

Technical Services Ship Standards Bay 2/22, Spring Place 105 Commercial Road Southampton SO15 1EG

RECENT AMENDMENTS

The amendments made in the most recent publication are shown below, amendments made in previous publications are shown in the document Amendment History.

Version Number	Status / Change	Date	Author Reviewer	Content Approver	Next Review Date/Expiry Date
02.21	Update to Radar transponders section	19/01/21	l Platts/D Fenner	G Stone	19/01/23
	Amended section numbering				
09.21	Update references to MSN1872 Amendment No.2	31/08/21	D Fenner	G Stone	31/08/23
	 Update to text in Lifejackets section 				
	• Update to Rescue Boats Exemptions				

MAIN CONTENTS

<u>PREF</u>	REFACE	
<u>RECEI</u>	NT AMENDMENTS	3
MAIN	CONTENTS	4
<u>10.1</u>	GENERAL	7
<u>10.2</u>	COMPATIBILITY	7
<u>10.3</u>	SAFETY AWARENESS	8
<u>10.4</u>	TYPE APPROVAL	8
<u>10.5</u>	READY AVAILABILITY	8
<u>10.<mark>6</mark></u>	SERVICING OF LSA EQUIPMENT	9
<u>10.<mark>7</mark></u>	FISHING VESSELS AND OTHER UK SHIP CLASSES	9
<u>10.</u> 8	EXEMPTIONS/EXCEPTIONS	10
<u>10.<mark>9</mark></u>	LIFEJACKETS	12
<u>10.<mark>10</mark></u>	LIFEBUOYS	13
<u>10.<mark>11</mark></u>	PYROTECHNICS	15
<u>10.<mark>12</mark></u>	IMMERSION SUITS	15
<u>10.<mark>13</mark></u>	THERMAL PROTECTIVE AIDS	16
<u>10.<mark>14</mark></u>	VHF RADIO (PORTABLE)	17
<u>10.<mark>15</mark></u>	RADAR TRANSPONDERS (SARTS)	19
<u>10.<mark>16</mark></u>	SATELLITE EMERGENCY POSITION INDICATING RADIO BEACON (EPIRB)	21
<u>10.<mark>17</mark></u>	RIGID RESCUE BOATS	23

10. <mark>18</mark>	RESCUE BOAT EQUIPMENT	25
10. <mark>19</mark>	RESCUE BOAT FITTINGS	26

<u>10.<mark>20</mark> The Hi</u>	RIGID INFLATED RESCUE BOATS - TYPE A (BOATS WHERE THE INFLATED TUBE IS A COLLAR FITTED AF	ROUND 26
<u>10.<mark>21</mark></u>	FAST RESCUE BOATS	27
<u>10.<mark>22</mark></u>	INFLATED RESCUE BOATS	27
<u>10.<mark>23</mark></u>	INFLATED BOATS (NON SOLAS BOATS)	27
<u>10<mark>.24</mark></u>	SURVIVAL CRAFT	27
<u>10<mark>.25</mark></u>	TOTALLY ENCLOSED LIFEBOATS	28
<u>10.<mark>26</mark></u>	LIFEBOAT PROPULSION	28
<u>10.<mark>27</mark></u>	LIFEBOAT FITTINGS	32
<u>10.<mark>28</mark></u>	RETRO REFLECTIVE MATERIAL	33
<u>10.<mark>29</mark></u>	MARKING	33
<u>10.<mark>30</mark></u>	EVALUATION, TESTING AND APPROVAL OF LSA AND ARRANGEMENTS	34
<u>10.<mark>31</mark></u>	AVAILABILITY AND STOWAGE OF LSA AND SURVIVAL CRAFT	34
<u>10.<mark>32</mark></u>	EMBARKATION INTO SURVIVAL CRAFT	36
<u>10.<mark>33</mark></u>	OPERATIONAL READINESS, MAINTENANCE AND INSPECTIONS	36
<u>10.<mark>34</mark></u>	MAINTENANCE	36
<u>10.<mark>35</mark></u>	SERVICING OF LSA	36
<u>10.<mark>36</mark></u>	ON BOARD TRAINING AND INSTRUCTIONS	37
<u>10.<mark>37</mark></u>	TRAINING MANUAL	37
<u>10.<mark>38</mark></u>	PERIODIC SURVEYS OF LIFE SAVING APPLIANCES	38

10.39 LIFEBOAT AND RESCUE BOAT DISENGAGING GEARS AND SIMILAR ARRANGEMENTS

DOCUMENT AMENDMENT HISTORY

56

47

10.1	GENERAL	
10.1.1	The relevant regulations and requirements are set out at the beginning of each	
	section. The guidance should also be applied, as far as practical.	
<u>10.1.2</u>	These instructions do not give information on the number and type of Life Saving Appliances (LSA) that is required by each fishing vessel. The attending surveyor will have to view the individual regulations covering size and area of operation of the fishing vessel involved.	
10.2	COMPATIBILITY	
10.2.1	The surveyor should ensure that all LSA is compatible. This can be shown by demonstration where information from manufacturers or previous survey is not available.	
10.2.2	Examples are - lifejackets and immersion suits should be capable of being worn together, when required, and a normal evacuation carried out. If the immersion suit is not required to be carried the surveyor should consider whether safety would be enhanced by its carriage? If it is not compatible with the required lifejacket an advisory word of caution may be more appropriate than a deficiency.	
10.2.3	Lifejackets lights should be automatic wherever possible. Approved manual lights are acceptable but the surveyor should point out the issues of manual activation in cold waters or the issues with an unconscious casualty. They should be secured as high as possible to be visible when a casualty is floating normally in the water.	
10.2.4	Lifejackets are encouraged to be worn at all times on deck. Working lifejackets may be carried in addition to the statutory requirements but should not be included in the certification process.	
10.2.5	Hydrostatic release unit should be acceptable for the size and type of liferaft. It is apparent that a number of smaller vessels covered by MCA certification are likely to be carrying life rafts which are smaller than those carried on board vessels which are subject to SOLAS requirements.	
10.2.6	There may be some doubt as to whether or not the hydrostatic release units supplied for SOLAS size life rafts are appropriate for life rafts of below SOLAS size.	
10.2.7	In cases where smaller than SOLAS size life rafts are fitted, and there is any doubt with respect to the compatibility of HRU and the raft itself, then confirmation is to be sought from manufacturers and/or equipment suppliers that the breaking strength of the weak link and the size of the raft are compatible.	
10.2.8	Hammar have also produced a small green cartridge type weak link which is for attaching to the standard Hammar HRU. They are now recommending that the new green coloured HRU should be used for small rafts.	



10.3 SAFETY AWARENESS

- 10.3.1 The attending surveyor/inspector is to ensure that any safety campaign is highlighted during the survey.
- 10.3.2 Local focal points (SCOTNI, Eastern and Western) for Fishing and Life Saving Appliances will issue information.
- 10.3.3 This can be achieved by forwarding literature to the Skipper but may be better served by demonstration on board.

10.4 TYPE APPROVAL

- 10.4.1 The surveyor should ensure that all LSA equipment is type approved (MED) where required. This should be verified at initial surveys. Equipment that is MED approved should follow the requirements of <u>The Merchant Shipping (Marine Equipment) Regulations 1999</u> and <u>MSN 1734 (M+F)</u> Type Approval of Marine Equipment (EC Notified Bodies).
- 1.0.4.2 At flag ins the flagging in surveyor is to complete a list of non-MED equipment and verify that this equipment is type approved against the relevant standard. The list of non-MED equipment is to be attached to the file and the Fishing Vessel Certificate (FVC).
- 10.4.3 Any non-MED equipment which has been replaced must be replaced with MED type approved equipment.
- 10.4.4 At annual renewal surveys changes to the equipment list is to be updated.
- 10.4.5 The file and Record of Equipment are to be updated at renewal surveys.

10.5 READY AVAILABILITY

10.5.1 Requirements are contained in MSN 1871, Chapter 7; in MSN 1872, Chapter 7; and in MSN 1873, Chapter 7.

- 10.5.2 It is essential the surveyor ensures that all safety equipment is ready for immediate use. This includes equipment on board which is not required by legislation.
- 10.5.3 Any life saving equipment found on board should be fit for purpose and ready for use.
- 10.5.4 The attending surveyor should always record this as a deficiency, even if the deficiency is rectified before the survey/inspection is completed. These records are vital to show if any programme is having a measurable outcome.
- 10.5.5 Inspection of the life saving appliances, including lifeboat equipment, must be carried out monthly using a checklist to ensure that they are complete and in good order. A report of the inspection shall be entered in the logbook.

10.6 SERVICING OF LSA EQUIPMENT

10.6.1 Requirements are contained in MSN 1871, Chapter 7; in <u>MSN 1872</u>, Chapter 7; in <u>MSN 1873</u>, Chapter 7; and in MGN 548 and MGN 553.

- 10.6.2 Depending on the type of inspection/survey being carried out the following equipment should be verified as having been serviced by an approved service provider:
 - Lifeboat davits (flag in, initial, annual and renewal survey).
 - Lifeboat release gear (flag in, initial, annual).
 - Rescue boat davit and release hook (flag in, initial, annual and renewal survey).
 - Inflatable rescue boat (flag in, initial, annual and renewal survey).
 - Solid rescue boat (flag in, initial and renewal).
 - Liferaft davit (flag in, initial, annual and renewal survey).
 - Davit launched liferaft release hook (flag in, initial, annual and renewal survey).
 - Inflatable liferaft (flag in, initial, annual and renewal survey).
 - Hydrostatic release units for life rafts and EPIRB (flag in, initial, annual and renewal survey).
 - EPIRB/PLB (flag in, initial, annual and renewal survey).
 - Inflatable lifejackets (flag in, initial, annual and renewal survey).
 - Immersion suits (flag in and as per manufacturer's instructions).

10.7 FISHING VESSELS AND OTHER UK SHIP CLASSES

It should be noted that some fishing vessels may have dual certification. An example may be a Small Commercial Vessel Certificate in addition to the Fishing Vessel Certificate or a Class VI passenger and Fishing vessel certificate.

10.<mark>7</mark>.1

- 10.7.2 The requirements for LSA are known to have different issues. For example, just because an under 15m meets the requirements of a fishing vessel it does not necessarily mean that meets the requirements of a code vessel.
- 10.7.3 The surveyor/inspector should ensure he is aware of what legislation or code he/she is applying before commencing the work.

10.8 EXEMPTIONS/EXCEPTIONS – RESCUE BOATS

10.8.1 Requirements are contained in MSN 1873, Chapter 7, section 7.2.1.4.

- 10.8.2 There are some over 24m metre vessels which have exemptions from the carriage of rescue boats.
- 10.8.3 Life-Saving Appliances and Arrangements for vessels of 45 m in length and over are determined as per Torremolinos Convention and exemption granted be shall communicated to the International Maritime Organization(IMO) to the extent necessary to confirm that the level of safety is adequately maintained and the IMO shall circulate such particulars to the Parties for their information. Therefore, the policy is not to grant exemption to this size of vessel.
- 10.8.4 Life-Saving Appliances and Arrangements for vessels 24 m to 45 m in length are determined by COUNCIL DIRECTIVE 97/70/EC of 11 December 1997 setting up a harmonised safety regime for fishing vessels of 24 metres in length and over (the EU Directive).
- 18.8.5 The EU Directive requires that all vessels over 24 m but less than 45 metres in length shall be provided with a rescue boat, "except where the administration is satisfied that because of the size and the manoeuvrability of the vessel, the near availability of search and rescue facilities and meteorological warning systems, the operation of the vessel in areas not susceptible to heavy weather or the seasonal characteristics of the operation, such provision is unnecessary." The EU requirement is repeated in <u>MSN 1873</u> Chapter 7.2.1.4(ii).
- 10.8.6 For all new vessels and those at an early stage in construction, a rescue boat should be provided.
- 10.8.7 Under the now revoked Fishing Vessels (Safety Provisions) Rules 1975, some vessels were issued with a rescue boat exemption based on the manning of six or fewer crew, as it was considered impractical to operate a rescue boat with this number considering one crew member in the water. Such exemptions are not considered valid as the regulations are no longer in force and the conditions of the exemption are not in line with the current requirements. The exemption is to be reviewed in line with the requirements contained in <u>MSN 1873</u>.
- 10.8.8 For existing vessels, we support the consideration of any exemption request, as soon as practical, by the proposed panel review. Waiting until to the renewal survey was not considered to be a good idea, because it would then not allow the operator time to plan for the fitting at the survey. Note that just because space

does not appear to be available in its current form does not mean it is not practical to retrofit one. Platforms may be constructed, and novel means of stowage can be considered, where there is a will and need to fit one. If a platform is constructed, then potential problems with working at height and wheelhouse visibility need to be taken in to account.

- 10.8.9 Following discussions at a local level with various interested parties in the North East of Scotland the following factors can be taken into consideration when proposed as an equivalence for twin rig fishing vessels 24m to 45m only:
 - 1. The vessel shall be provided with good manoeuvrability and it is likely that bow and stern thrusters on larger vessels will be required together with port and starboard bridge wing controls so that recovery of the helpless person can be observed from the navigating bridge.
 - 2. The vessel shall be provided with a rescue basket fitted with retro reflective tape visible from the sides and above and be provided with powered recovery arrangements. The powered recovery arrangements need not be dedicated to the rescue basket.
 - 3. Personnel nominated to assist with the recovery of the casualty into the rescue basket shall wear immersion suits and have safety harnesses.
 - 4. Cranes used for deployment of such devices are to be operated from a safe and protected location, situated at a level not lower than the shelter deck, with good visibility of the over-side area of deployment. The crane shall be required to be certificated in accordance with the Code of Safe Working Practices for Merchant Seamen. A 2.2 SWL static test as applied to LSA is not required. These cranes shall be capable of hoisting the full weight of the device and at least 6 survivors. [The crane should be subject to LOLER regulations and tested accordingly (refer to chapter 19 of COSWP, including the testing requirements in 19.19.3 and 19.20)].
 - 5. The crane shall have two independent forms of power, which may be either electric or stored hydraulic.
 - 6. A detailed risk assessment will be required to show that all mitigating actions are in place to prevent man overboard. [MGN 571]
 - It will be a requirement that man overboard drills with a dummy are demonstrated at sea with nets over the side to represent a realistic scenario.
 [MGN 570]
- 10.8.10 Other equivalencies may be considered for Existing Vessels so that the level of safety and the ability of the vessel to act as its rescue boat is adequately maintained. Any proposals shall be reviewed by the Consultant Surveyors to ensure consistency in the application of the requirement for Rescue Boats.

10.	1	0. <mark>9</mark>	LIFEJACKETS
10.	1	0. <mark>9</mark>	LIFEJACKET

10.9.1 GENERAL

- 10.9.1.1 Requirements are contained in MSN 1871, Chapter 7; in MSN 1872, Chapter 7; and in MSN 1873, Chapter 7. 10.<mark>9</mark>.1.<mark>2</mark> No lifejacket should be passed as part of the statutory equipment of a ship unless it:is of an accepted type; complies in all respects with the accepted specification; is in good condition and fit for the service intended. On board repairs or modifications are not acceptable. 10.<mark>9</mark>.1.<mark>3</mark> Any lifejacket supplied new should be MED approved with required wheelmark and Type approval certification. 10.9.1.4 They can be solid-filled type or comply with BS EN 396 or BSEN 399, which will eventually be replaced by EN ISO 12402, with automatic gas inflation and at least 150 Newtons of buoyancy. It should be fitted with retro-reflective tape, a type approved light and a whistle. 10.9.1.4 Lifejackets for seagoing ships in accordance with ISO 12402-1 are intended primarily for use on seagoing ships under IMO rules. 10.9.1.5 PFD, performance level 275, in accordance with ISO 12402-2 are intended primarily for offshore use and by people of significant weight or who are using items of significant weight and thus require additional buoyancy. They are also of value to those who are using clothing which traps air and which will adversely affect the self-righting capacity of the lifejacket. They are designed to ensure that the user is floating with their mouth and nose clear of the surface at an angle and with sufficient freeboard to limit mouth immersions in waves. Note: when fitted with emergency light and whistle can be counted as abandon ship lifejacket required by MSN1871 Amendment No.2 The Code of Practice for the Safety of Small Fishing Vessels of less than 15m Length Overall, or any superseding document. 10.9.1.6 PFD, performance level 150, in accordance with ISO 12402-3 are intended for general offshore and rough weather use where a high standard of performance is required. As tested, they will turn an unconscious person in swimming attire into a safe position. Additionally, they should maintain a fully clothed person in a safe position with no subsequent action by the user. Minimum accepted performance level for inflatable PFDs on Fishing Vessels 10.9.1.7
- 10.9.1.8 9.3.21.4.1 The minimum accepted performance level for an automatically operating PFD or automatically inflated PFD on a fishing vessel is 150N.

- 10.9.1.9 PFDs which require a secondary donning action and/or additional positioning are not acceptable given that the critical cold shock period occurs immediately on entering the water.
- 10.9.1.10 PFDs must always be worn in accordance with Manufacturers instructions.
- 10.9.1.11 Inflatable lifejackets are required to be serviced annually at an approved service station.
- 10.9.1.12 Lifejackets must be either in a deckhouse or other dry and readily accessible position; and have stowage positions clearly and permanently marked.

10.9.2 DONNING INSTRUCTIONS

- **10.9.2.1** Lifejacket manufacturers should provide illustrated directions for donning and adjustment. This should be displayed and held with vessels training information (where required).
- 10.10 LIFEBUOYS

10.<mark>10</mark>.1 GENERAL

- 10.10.1.1 Requirements are contained in MSN 1871, Chapter 7; in MSN 1872, Chapter 7; and in MSN 1873, Chapter 7.
- 10.10.1.2 Lifebuoys should be marked with the vessel name and port of registry or fishing number with reflective tape. They may be circular or horseshoe in shape on under 15m fishing vessels.
- 10.10.1.3 Lifebuoys made of synthetic materials should be embossed with the manufacturer's trademark, or trade name of the lifebuoy.
- 10.10.1.4 Lifebuoys should be of a standard international orange colour or if an old cork lifebuoy covered with a canvas material painted red and white.
- 10.10.1.5 Any lifebuoy supplied new should be MED approved with required wheelmark and Type approval certification.

10.10.2 LIFEBUOY SELF-IGNITING LIGHTS

10.10.2.1 Lights of this type must be self-igniting in water, and be capable of burning brightly for at least 2 hours. The lights should be stowed to prevent accidental or premature ignition. They may be operated by water activated cells or dry batteries. The line should be attached to the light at the level of the centre of flotation where possible to prevent inclination of the signal in a seaway.

10.10.3 LIFEBUOY SELF-ACTIVATING SMOKE SIGNALS

10.10.3.1 These are usually combined with the man overboard lights for bridge wing lifebuoys. They should be secured as per manufacturer's instructions. It is essential that the markers are connected with the lifebuoy with a suitable length of line which will activate the smoke signal when the buoy is released.

10.10.4 LIFEBUOY BUOYANT LIFELINES

- 10.10.4.1 Surveyors should note that the property of grip is essential in this application and should ensure that a suitable type of rope is used. They should be of a suitable length, not less than twice the height at which it is stowed above the waterline in the lightest seagoing condition, or 30 metres, whichever is greater. For handling characteristics and its ability to float 8mm, polypropylene should be used. Such lifebuoys should not have self-igniting lights.
- 10.10.4.2 A buoyant quoit fitted with 18m of floating line can be fitted in place of one of the required lifebuoys.

10.10.5 STOWAGE OF LIFEBUOYS

- 10.10.5.1 At least two of the lifebuoys provided with self-igniting lights in accordance with paragraph 10.12.2 must be provided with self-activating smoke signals and shall, where practicable, be capable of quick release from the navigating bridge.
- 10.10.5.2 Where four or more lifebuoys are required by the Regulations, two of them should be carried in brackets or cleats attached to the deck rails or some other convenient place near the stern of the ship. The remainder, if any, should be carried in a similar manner, well distributed on the weather deck rails. In small ships where there is difficulty in arranging for the quick release of lifebuoys from the navigating bridge, the surveyor may waive this requirement at his discretion if he is satisfied that the best alternative arrangement is made to ensure that the lifebuoys are readily available.
- 10.10.5.3 Lifebuoys should not be permanently secured in any way.
- 10.10.5.4 At least half of the number of lifebuoys must be provided with self-igniting lights.
- 10.10.5.5 At least one lifebuoy on each side of the vessel shall be fitted with a buoyant lifeline equal in length to not less than twice the height at which it is stowed above the waterline in the lightest seagoing condition, or 30 metres, whichever is greater. Such lifebuoys should not have self-igniting lights.

10.11 PYROTECHNICS

10.<mark>11</mark>.1 GENERAL

- 10.11.1.1 Requirements are contained in MSN 1871, Chapter 7; in MSN 1872, Chapter 7; and in MSN 1873, Chapter 7.
- 10.11.1.2 Every vessel must be provided with means of making effective distress signals by day and by night. All pyrotechnic distress signals shall be packaged in a watertight container and shall be clearly and indelibly labelled to indicate their purpose.
- 10.11.1.3 Distress signals must be of an approved type. They shall be so placed as to be readily accessible and their position must be plainly indicated.
- 10.11.1.4 Pyrotechnic signals should be inspected regularly and replaced if any doubt exists as to their condition. In any case, all pyrotechnics should be renewed within four years from the date of manufacture. Pyrotechnics in liferafts may be retained if their expiry date is 6 months or more after the liferaft servicing date provided they appear to be in good condition.
- 10.11.1.5 Parachute flares -supplied new should be MED approved with required wheelmark and Type approval certification.
- 10.11.1.6 Handheld flares- supplied new should be MED approved with required wheelmark and Type approval certification.
- 10.11.1.7 Buoyant smoke signals supplied new should be MED approved with required wheelmark and Type approval certification.
- 10.11.1.8 Line throwing apparatus- supplied new should be MED approved with required wheelmark and Type approval certification.

10.<mark>11</mark>.2 DISPOSAL

- **10.11.2.1** Disposal of any out of date LSA equipment should be carried out in a responsible manner in line with current legislation and guidance.
- **10.12 I**MMERSION SUITS

10.<mark>12</mark>.1 GENERAL

- 10.12.1.1 Requirements are contained in MSN 1873, Chapter 7.
- 10.12.1.2 No immersion suit or anti-exposure suit should be passed as part of the statutory equipment of a ship unless it:
 - is of an approved type and marked as such;
 - complies in all respects with the accepted specifications;

- is in good condition and fit for the service intended; and
- there is a size suitable for each person on board.

10.12.2 DONNING INSTRUCTIONS

- 10.12.2.1 Manufacturers should ensure that illustrated instructions for donning, adjustment and maintenance of immersion suits or anti-exposure suits are supplied with each suit.
- 10.12.2.2 Instructions suitably protected from damage should be available for display and for inclusion into training and maintenance manuals, if carried. Consideration should be given to where there is adequate space for donning the suit.

10.12.3 REPAIR AND SERVICING OF IMMERSION SUITS

- 10.12.3.1 Repairs and servicing of immersion suits should only be carried out by the manufacturers or their authorised agents. This does not include carrying out work such as replacing independent light or lubricating a zip.
- 10.12.3.2 Servicing would be required if the surveyor is in doubt over the watertight integrity of seams etc. or the obvious degradation to the material

10.12.4 STOWAGE OF IMMERSION SUITS

10.12.4.1 The stowage position of immersion suits must be in a place where they are readily available for collection by crews. Care should be taken to ensure that conditions in the stowage position chosen will not adversely affect the immersion suit.

10.13 THERMAL PROTECTIVE AIDS

10.<mark>13</mark>.1 GENERAL

10.13.1.1 Requirements are contained in MSN 1873, Chapter 7.

- 10.13.1.2 No thermal protective aid should be passed as part of statutory equipment of a ship unless it:
 - is of an approved type;
 - complies in all respects with the accepted specifications; and
 - is in good condition and fit for the service intended.

10.13.2 DONNING INSTRUCTIONS

- 10.13.2.1 Manufacturers should provide illustrated instructions for donning and discarding thermal protective aids with each aid.
- 10.13.2.2 Instructions, suitably protected from damage, should be available for display and for inclusion into training and maintenance manuals, if required.

10.14 VHF RADIO (PORTABLE)

10.<mark>14</mark>.1 GENERAL

- 10.14.1.1 Requirements are contained in MSN 1871, Chapter 7 Annex 2; in MSN 1872, Chapters 7 and 9; and in MSN 1873, Chapters 7 and 9.
- 10.14.1.2 Radio equipment forming part of a ship's life-saving appliances will perform one or more functional requirements when used in a survival craft thereby enhancing the success of any Search and Rescue (SAR) operations. These include:
 - transmit to-shore distress alerts;
 - transmit and receive on-scene communications; and
 - transmitting signals for locating.
- 10.14.1.3 The two-way (VHF) Radiotelephone apparatus should be portable. The equipment should be capable of being used for on-scene communication between survival craft, between survival craft and ship and between survival craft and rescue unit. It may also be used for on-board communications when capable of operating on appropriate frequencies.
- 10.14.1.4 Survival-craft portable VHF radiotelephones (SCP VHF) carried on board fishing vessels, shall:
 - be fitted with a lanyard for attachment to a person;
 - if not provided with a spare battery then an additional SCP VHF of an appropriate certification and standard as below shall be provided;
 - the equipment shall be stowed on or near the bridge in a dry and readily accessible location, clearly marked.
- 10.14.1.5 The equipment shall have the following Certification and confirm to the following technical standards:

Length	Equipment Certification	Technical Standard
45m and over	Marine Equipment	See note 1 below
	Directive (MED) –	
	Wheelmark	
24m and over built after	Marine Equipment	See note 1 below
1 January 1999	Directive (MED) –	
	Wheelmark	
None of the above AND	Marine Equipment	See note 1 below
10m and over provided	Directive (MED) –	
with a liferaft	Wheelmark	
	OR	
	MCA approved type	See 10.14.1.7 below

Note 1

This equipment must be type approved to one of the following standards:

ETSI ETS 300 225 2nd edition

ETSI ETS 300 225 3rd edition

ETSI EN 300 225 (v1.4.1)

ETSI EN 300 225 V1.5.1 (2015-12)

IEC 61097-12 (1996).

IEC 61097-12:1996+AMD1:2017 (the Consolidated version is also referred to as Ed. 1.1)

- 10.14.1.6 For equipment of an MCA approved type, when a SCP VHF is replaced, the new equipment should conform to the latest version of ETSI EN 300 225 which is V1.5.1 as of the date of this Instruction.
- 10.14.1.7 The certification and technical standards required for existing equipment by vessel build date is as follows:

Vessels build	Certification	Technical standard
Prior to The Merchant Shipping	Type-approved	MPT 1251 with a waterproof cover
(Radio) (Fishing Vessels)	Type-approved	MPT 1253
Regulations 1999 coming into force 1st January 2000	R&TTE ¹ Directive or RED ² /CE marked	ETSI I-ETS 300 225 OR one of the standards listed in Note 1
After The Merchant Shipping (Radio) (Fishing Vessels) Regulations 1999 coming into force 1st January 2000 but before 1st October 2006	R&TTE Directive or RED/CE marked	one of the standards listed in Note 1
After 1st October 2006	R&TTE Directive or RED/CE marked	one of the standards listed in Note 1 excluding ETSI ETS 300 225 2nd edition



- R&TTE Directive or RED equipment shall also:
- have been tested to be waterproof by design to IPx7 OR IPx8 (IP = Ingress Protection, x=any digit);
- have been tested to show that the battery life is at least 8 hours.

¹ Radio and Telecommunications Terminal Equipment

² Radio Equipment Directive

- 10.14.1.9 That equipment to be used for Life-Saving purposes should be clearly identified as such through being either of a highly visible yellow/orange colour or marked with a surrounding yellow/orange marking strip.
- 10.14.1.10 NOTE: MSN1871 incorrectly states than Open Vessels of 12-15m and Decked Vessels of 10m to less than 15m should have DSC Fixed and Handheld VHF Radios. This should read that these vessels must have a DSC Fixed or Handheld VHF Radio

10.<mark>14</mark>.2 POWER SUPPLY

- 10.14.2.1 The source of energy should have a capacity to ensure at least 8 hour, preferably 24 hour operation at the highest rated power of the equipment with a duty cycle of 1:9. This duty cycle is defined as 6 seconds transmission, 6 seconds reception above squelch opening level and 48 seconds below squelch opening level. The source of energy should comply with the following:
 - A sealed primary battery which should be:
 - of a type which will not emit substances which may be injurious to personnel, or damaging to the equipment or fabric of the survival craft. This requirement should be met whether the power source is in a stored condition or normal use;
 - securely mounted and clearly marked with the shelf life whose expiry should not be less than 2 years from the date of survey; and
 - the battery should have sufficient capacity so that routine testing of 2 minutes once per week should not reduce its capacity below that needed to conform to the operational requirements recommended above. Where the battery is used to supply power to any other equipment, sufficient capacity should be available to operate this equipment at its maximum rated power for the period recommended in addition to the radio apparatus.
- 10.14.2.2 Batteries should be disposed of strictly in accordance with manufacturer's instructions.
- **10.15** RADAR TRANSPONDERS (SARTS)

10.<mark>15</mark>.1 GENERAL

- 10.15.1.1 Requirements are contained in MSN 1873, Chapter 7 Section 2.
- 10.15.1.2 The equipment should be kept on either side of the ship in a suitable place ready to be moved into a survival craft in case of emergency; where only one is required, it should be located at a suitable location for moving into the survival craft. In ships where the disposition of superstructures or deck houses is such as to involve substantial fore and aft separation and, where two transponders are carried, they should not be located in the same area of superstructure or in the same deck house.

- 10.15.1.3 The equipment should be clearly marked with the manufacturer's identity, type or model identification, serial number, brief operating instructions and the expiry date for the primary batteries used. The minimum safe distance from the standard or magnetic steering compass at which the equipment may be installed should also be marked. The arrangements made in individual ships and/or survival craft should be determined to the satisfaction of the marine surveyor in consultation with the radio surveyor who should inspect the equipment as part of each survey of Life-Saving Appliances.
- 10.15.1.4 Developments in marine technology have led to the production of a new transponder that transmits on frequencies dedicated for AIS. Radar transponders are those that transmit on 9GHz band. Developments in marine technology have led to the production of a new transponder that transmits on frequencies dedicated for AIS.

SOLAS has been amended to allow reference to be made to the two types of devices.

- a search and rescue device capable of operating on 9GHz now known as a radar search and rescue transponder (SART)
- a search and rescue locating device capable of operating on frequencies dedicated for AIS now known as an AIS search and rescue transmitter (AISSART).
- 10.15.1.5 <u>MSN 1873</u> amend 1, paragraph 7.2.10 only refers to the carriage of SARTs, one of these may be the radar transponder required by the Merchant Shipping (Radio) (Fishing Vessels) Regulations 1999. It is acceptable to have one of the search and rescue location devices to be an AISSART, however the locating device required by Global Maritime Distress Safety System (GMDSS) functional requirement of transmitting and receiving signals for locating by radar operating in the frequency band 9,300-9,500 MHz must be a SART.
- 10.15.1.6 Refer to MSIS27 Chapter 12, section 12.6.10.

10.15.2 SECURING THE EQUIPMENT IN LIFERAFTS

10.15.2.1 Every transponder should be provided with fittings suitable for mounting in each liferaft at a height of not less than 1 metre above the water line. These fittings should be attached to, or located adjacent to, the radar transponder at all times. Clear instructions on how to use the fittings in an emergency should be marked on the radar transponder or provided in a suitable format for carrying on to the survival craft. It is acceptable to mount the equipment within the liferaft, e.g. 'hang', the equipment will operate satisfactorily. Alternatively, the radar transponder may form an integral part of the survival craft, if so, the transponder should be included in the inflatable liferaft equipment when the liferaft is subject to prototype testing.

10.15.2.2 For vessels operating in the Northern Region or Southern Oceans, every lifeboat, rescue boat and liferaft shall permanently be equipped with an approved radar transponder (SART) capable of operating in the 9 GHz band.

10.16 SATELLITE EMERGENCY POSITION INDICATING RADIO BEACON (EPIRB)

10.<mark>16</mark>.1 GENERAL

- 10.16.1.1 Requirements are contained in MSN 1871, Chapter 7; in MSN 1872, Chapter 7; and in MSN 1873, Chapter 7.
- **10.16.1.2** The equipment should be clearly marked with the manufacturer's identity, type or model identification, serial number, brief operating instructions and the expiry date for the primary batteries used. EPIRB's should be annually tested for all aspects of operational efficiency, with special emphasis on checking the emission on operational frequencies, coding and registration. The arrangements made in individual ships should be determined to the satisfaction of the marine surveyor in consultation with the radio surveyor.

10.16.2 PERFORMANCE STANDARDS

- **10.16.2.1** The EPIRB should conform with a performance standard adopted by the IMO through Resolution. If operating on 406 MHz the EPIRB should conform with:
 - on renewal, conform to IMO MSC 471(101). The Radio and Telecommunication Terminal Directive Declaration of Conformity shall include reference to IEC 61097-2 or EN 300 066 or the Marine Equipment Directive Annex referenced by the Compliance Certificate shall be A.1/5.6; and
 - if installed on or after 23 November 1996 or on renewal, conform to IMO Resolution A.810 (19). The Radio and Telecommunication Terminal Directive Declaration of Conformity should include reference to IEC 61097-2 or EN 300 066 or the Marine Equipment Directive Annex referenced by the Compliance Certificate should be A.1/5.60;
 - if installed before 23 November 1986, Assembly Resolution A.763(18); or
 - if installed before 4 November 1994, Assembly Resolution A.763(18), except that they need not be provided with the 121.5 MHz homing beacon required by 2.3.14 of part A thereof.
 - if operating on the INMARSAT system the EPIRB should conform with:
 - if installed on or after 23 November 1996, Assembly Resolution A.812(19); or
 - if installed before 23 November 1996, Assembly Resolution A.661(16).

10.16.3 TESTING OF EQUIPMENT

10.16.3.1 Satellite EPIRBs are provided with a 'self-test' facility which a surveyor may wish to activate. Should the beacon 'fail' the 'self-test' it must be withdrawn from service. The EPIRB should not be removed from its float-free arrangements other than by an appropriately qualified engineer. Should it be suspected that the EPIRB

has been activated inadvertently, in the United Kingdom, the nearest MCA Marine Rescue Co-ordination Centre (MRCC) must be contacted IMMEDIATELY and informed of the ship's name, location and, if available, the EPIRB identification. Alternatively, contact the MCA on 0870 600 6505. Outside of the United Kingdom all efforts should be made to contact the appropriate Rescue Co-ordination Centre for the sea area concerned.

10.<mark>16</mark>.4 SITING OF EQUIPMENT

- 10.16.4.1 The installed EPIRB should be located in such a position that:
 - upon foundering, it will automatically float free from the ship without hindrance from any item of equipment or superstructure; and
 - it may be easily released manually and brought to the survival craft.
- 10.16.4.2 Surveyors should pay particular attention to the first requirement and great care should be taken when assessing the appropriateness, or otherwise, of the location adopted. Under no circumstances should this requirement be compromised to fulfil any additional functions the EPIRB may be required to perform. Where this is not practicable using a single EPIRB, additional equipment should be provided.

10.16.5 FLOAT FREE ARRANGEMENTS

10.16.5.1 The float free arrangements should carry a label indicating clearly the operating instructions for manual release. The installed EPIRB should be capable of local manual activation (remote activation may also be provided from the navigating bridge) while the device is installed in the float-free mounting. Any connection to the EPIRB, for example for the purpose of supply of data or power, should be corrosion resistant, protected against accidental activation and must not in any way inhibit the release of the beacon in times of emergency. Any hydrostatic release provided should be clearly marked with the date of expiry and tested in accordance with the manufacturer's instructions to ensure satisfactory operation.

10.16.6 PERSONAL LOCATOR BEACONS

10.16.6.1 On vessels of less than 15m, if an EPIRB is carried, then Personal Locator Beacons can be either 406 MHz and comply with EN 302 152 or be AIS. If no EPIRB is carried, then PLBs must be 406MHz and comply with EN 302 152. This is because the EPIRB is considered to be the mandatory equipment and the PLB is a voluntary addition. Furthermore, on crewed vessels, some skippers may prefer AIS PLBs because this will allow them to locate crew in the water.

10.16.6.2 On single handed vessels, PLBs shall be 406 MHz PLBs as the AIS is unlikely to notify the Coastguard of Man Overboard.

10.16.6.3 All 406 MHz PLBs must be registered in accordance with <u>The Merchant Shipping</u> (EPIRB Registration) Regulations SI 2000, No. 1850 and <u>Merchant Shipping</u> Notice 1816 (M&F) – Mandatory Registration of Electronic Position indicating Radio Beacons (EPIRBs). AIS PLBs do not require registration at the Beacon Registry.

- 10.16.6.4 Personal Locator Beacons should be worn whilst working on the open decks of fishing vessels at sea. When not being worn they should be stowed either in a deckhouse or other dry and readily accessible position.
- 10.16.6.5 Personal Locator Beacons should also be maintained in accordance with the manufacturer's instructions

10.17 RIGID RESCUE BOATS

10.<mark>17</mark>.1 GENERAL

- 10.17.1.1 The statutory requirements are contained in <u>MSN 1873</u>, Chapter 7, and LSA Code or Parts 1 and 7 of Schedule 2 of <u>MSN 1676(M</u>). A rigid rescue boat may be accepted as a lifeboat provided it also complies with the relevant requirements of Schedule 1. If a rescue boat is also one of the ships lifeboats, rapid recovery must be possible when loaded with its lifeboat equipment and the approved rescue boat complement or 6 persons whichever is the greater.
- 10.17.1.2 Rigid rescue boats should be MED approved. If the rescue boat is wheelmarked than this should satisfy the survey unless he has serious doubts regarding its construction.
- 10.17.1.3 If it is the express wish of the owner that a "Fast Rescue Boat" is to be used, then the boat must be of an approved type for Merchant Shipping use and the crew trained in the use of the craft on a continuous basis:
 - Fast rescue boats should be capable of manoeuvring, for at least 4 hours, at a speed of at least 20 knots in calm water with a suitably qualified crew of at least 3 persons and at least 8 knots with the full complement of persons and equipment;
 - The fast rescue boat shall be self-righting or capable of being readily righted by its launching crew, this righting equipment is in accord with <u>IMO Res.</u> <u>A656(16)</u> paragraph 1.4. Whichever arrangement is adopted, this "righting" is to be demonstrated to the satisfaction of the Nominated or Notified Body;
 - If the fast rescue boat is not to be operated by a suitably qualified and trained crew, the operating speed in the light condition must be limited to 50% of the maximum designed speed of the craft or 15 knots whichever is the least;
 - A suitable warning notice indicating the operating speed restriction is to be placed adjacent to the steering position. This notice will be in line with the requirements above.

10.17.2 POSITION OF MOTOR AND FUEL TANKS

10.17.2.1 Suitable arrangements should be made for stowing the motor and fuel tank ready for operation and protected from weather, but in a place which will not be

inaccessible in case of a machinery space or accommodation space fire. If the motor and fuel tank are stowed in the boat they should be stowed in such a manner that damage to the motor, fuel tank and the boat will not occur when the boat is stowed on board ship.

10.<mark>17</mark>.3 PETROL FUEL

10.17.3.1 The outboard petrol motor fuel capacity shall be the same as described for diesel engines.

10.17.4 SECURITY OF MOTOR

10.17.4.1 Suitable arrangements should be provided for securely attaching the engine and fuel tank to the boat and preventing damage to the fuel pipe.

10.17.5 NON-PORTABLE MOTORS

10.17.5.1 Where owners desire to fit a motor larger than that necessary to achieve a speed of over 6 knots the reason for such a request should be ascertained. Where these are justified the arrangement should be accepted, provided that the motor is attached to the boat at all times, the boat is attached to its launching and recovery device when the ship is on a voyage, and the device is capable of launching and recovering the boat without undue effort.

10.17.6 STOWAGE OF PETROL FOR OUTBOARD MOTORS

10.17.6.1

Where an outboard motor is fitted, a small quantity of spare petrol, about 100 litres, may be carried if it is stored in suitable containers in a specially constructed, well ventilated compartment situated in a safe place sited whenever possible on the open deck. Warning notices should clearly indicate the contents of the compartment and smoking should not be permitted in the vicinity. The warning notice may contain instructions to jettison the petrol containers overboard in case of shipboard fire in the vicinity of the store.

10.17.7 SPARE PARTS AND TOOLS

10.17.7.1 A kit of spare parts and tools should be provided and should include the following as appropriate:

- One set of spark plugs;
- Three propeller drive shear pins;
- Three propeller nut split pins;
- One starter rope;
- One spark plug spanner;
- One pair pliers;
- An instruction manual

10.<mark>17</mark>.8 PETROL FUEL TANK AND PIPE

- 10.17.8.1 Any petrol fuel tank should be specially protected against fire and explosion and separate from the engine. It must be of substantial construction of steel or other accepted material and the joints must not depend on solder for tightness. Provision should be made for sealing the air vent when the tank is not in use to prevent spillage of fuel.
- 10.17.8.2 The fuel pipe may be of suitable non-metallic material and its end connections should be self-sealing. Provision should be made for shutting off the fuel at the engine. Completed fuel tanks and their connections should be capable of withstanding hydraulic pressure corresponding to a head of at least 4.5 metres above the top of the tank. The maker's Certificate of Conformity may be accepted in this respect.

10.17.9 INSTRUCTIONS AND CONTROLS

10.17.9.1 Water resistant instructions for starting and operating the engine should be provided and mounted in a conspicuous place near the engine starting controls.

10.18 RESCUE BOAT EQUIPMENT

10.<mark>18</mark>.1 GENERAL

10.18.1.1The statutory requirements concerning the equipment of rescue boats are
contained in MSN 1873 Chapter 7 and LSA Code or Parts 7 and 8 of Schedule 2
of MSN 1676(M) and Parts 1, 2 and 3 of Schedule 3 of MSN 1676(M).

10.<mark>18</mark>.2 EQUIPMENT

- **10.18.2.1** The equipment to be carried in rescue boats is similar to that for lifeboats with the following exceptions:-
 - Paddles may be used instead of oars;
 - One boat hook, bucket, hatchet, fire extinguisher is to be carried instead of two items as in lifeboats;
 - Only one painter of sufficient length is required attached to a quick release device placed at the forward end of the rescue boat;
 - Additionally, these boats are required to be provided with a buoyant line of not less than 50 metres in length of sufficient strength to enable towing of a fully laden liferaft;
 - In the case of rigid inflated rescue boats, an efficient manually operated bellows or pump is required and also a repair kit in a suitable container for repairing punctures to the coated fabric of the buoyancy tubes; and
 - Additionally, in the case of inflated rescue boats and inflated boats a buoyancy safety knife and two sponges are required.

10.19 RESCUE BOAT FITTINGS

10.<mark>19</mark>.1 GENERAL

10.19.1.1The requirements are listed in MSN 1873, Chapter 7, and LSA Code or MSN1676(M)Schedule 2, Part 1, paragraph 5.

10.19.2 DRAIN VALVES

10.19.2.1 Where access is not possible at arm's length by an occupant other suitable means of closing the valve should be provided. Working instructions should be posted adjacent to the position indicator. The surveyor should be satisfied that the design and attachment to the main hull of the automatic drain valve is acceptable.

10.<mark>19</mark>.3 BAILING

10.19.3.1 Where rescue boats are not automatically self-bailing they should be provided with effective means of bailing. This is a particularly important item to consider when rescue boats fitted with outboard motors run astern.

10.20 RIGID INFLATED RESCUE BOATS - TYPE A (BOATS WHERE THE INFLATED TUBE IS A COLLAR FITTED AROUND THE HULL)

10.<mark>20</mark>.1 GENERAL

- 10.20.1.1 These rescue boats should be MED approved.
- 10.20.1.2 The statutory requirements are contained in LSA Code or Parts 1, 7 and 8 of Schedule 2 of <u>MSN 1676(M)</u> as appropriate, these are in many respects similar to those of Part 1 with the exception of:
 - they cannot be used as a lifeboat; and
 - buoyancy requirements differ.
- 10.20.1.3 Due account of the engine should be taken at the design stage and the details and plans submitted should include details of:-
 - Maximum power and weight of engine for which the boat has been designed.
 - Arrangements for securing engine, fuel tank and piping.
 - Stowage of fire extinguisher.

10.20.2 BUOYANCY

10.20.2.1 The total amount of buoyancy to support the boat with all of its equipment on board when flooded and open to the sea may be made up of inherent buoyancy or inherent buoyant material plus the volume of the inflatable compartments on one side (excluding the forward compartment inflated). ADDITIONAL inherent

buoyancy equal to 140 newtons of buoyancy force per person shall be provided for the number of persons the boat is permitted to accommodate.

10.21 FAST RESCUE BOATS

10.<mark>21</mark>.1 GENERAL

10.21.1.1 These fast rescue boats must be MED approved. The requirements of an FRC are stated in the LSA Code. No alternative is acceptable.

10.22 INFLATED RESCUE BOATS

10.22.1 GENERAL

10.22.1.1 These rescue boats are to be MED approved. The statutory requirements are contained in the LSA Code and Parts 1 and 2 of Schedule 3 of <u>MSN 1676(M)</u>.

10.23 INFLATED BOATS (NON SOLAS BOATS)

10.23.1 GENERAL

- 10.23.1.1 If an existing fishing vessel is found to be fitted with a non-MED inflated boat that is not carried as a statutory requirement then the following guidance should be considered.
- 10.23.1.2 The statutory requirements for inflated boats (also commonly known as a DOTI boat) are contained in Parts 1 and 3 of Schedule 3 of <u>MSN 1676(M</u>).
- **10.24 SURVIVAL CRAFT**

10.<mark>24</mark>.1 GENERAL

- 10.24.1.1 Requirements are contained in in <u>MSN 1873</u>, Chapter 7; <u>MSN 1676 (M)</u> and <u>MSN</u> 1677 (M).
- 10.24.1.2 All lifeboats should be MED approved. In the event that the surveyor is in doubt over the construction, fitting or equipment he can check the requirement against the annex attached.
- 10.24.1.3 It is not envisioned that fishing vessels will be fitted with fire or air protected lifeboats and these types have not been included in the instructions.
- 10.24.1.4 These are contained in LSA Code and Schedule 2, Part 1 of <u>MSN 1676(M</u>) or <u>MSN 1677(M).</u>
- 10.24.1.5 The lifeboat should have MED type approved certification.

10.24.1.6 The weight of the lifeboat, including fixed equipment, should be entered on the form. In the case of lifeboat of accepted design it will be sufficient to verify the weight of the prototype of the lifeboat concerned; surveyors should, however, be satisfied in all cases that, so far as is possible, the weight entered on the form is correct.

10.25 TOTALLY ENCLOSED LIFEBOATS

10.<mark>25</mark>.1 GENERAL

10.25.1.1 Totally enclosed lifeboats should comply with LSA Code or Parts 1, 2 and 4 of Schedule 2 of <u>MSN 1676(M)</u>.

10.25.2 WOODEN LIFEBOATS

10.25.2.1 Any inquiry or proposal to fabricate a wooden lifeboat should be referred to a Nominated or Notified Body.

10.25.3 STEEL LIFEBOATS

10.25.3.1 Any inquiry or proposal to fabricate a steel lifeboat should be referred to a Nominated or Notified Body.

10.25.4 ALUMINIUM ALLOY LIFEBOATS

10.25.4.1 Any inquiry or proposal to fabricate an aluminium lifeboat should be referred to a Nominated or Notified Body.

10.25.5 GLASS-REINFORCED PLASTIC LIFEBOATS

10.25.5.1 The lifeboat should be MED approved. In the event the surveyor has doubts over the construction of the boat the Annex Regarding GRP Manufacture and repair can be referred too.

10.26 LIFEBOAT PROPULSION

10.<mark>26</mark>.1 GENERAL

- 10.26.1.1 An MED approved boat should have a propulsion system meeting the requirements of LSA Code or Paragraph 4 Part 1 of Schedule 2 of <u>MSN 1676(M)</u>.
- 10.26.1.2 Non-MED lifeboats fitted to existing fishing vessels should comply with the following.

10.26.2 CERTIFICATE OF MATERIALS AND TESTS

- 10.26.2.1 The makers should normally furnish certificates covering the physical properties of the material of crankshaft, gearbox shafts and hydraulic tests of the cooling water spaces.
- 10.26.2.2 Alternatively, certificates issued by the following Nominated Bodies covering the engine and gearbox are acceptable:
 - The British Technical Committee of the American Bureau of Shipping
 - The British Committee of Bureau Veritas
 - The British Committee of Det Norske Veritas
 - The British Committee of Germanischer Lloyd
 - The British Committee of Lloyd's Register of Shipping
- 10.26.2.3 Alternatively, certificates issued by a Notified Body under the EU Marine Equipment Directive covering the engine and gearboxes are acceptable.

10.26.3 INTERMEDIATE AND PROPELLER SHAFTS

10.26.3.1 Intermediate shafts should have a diameter not less than that determined by the following formula:-

d = 100 {560 P/(t + 160)R}^{0.333}

where d = diameter of shaft in mm

P = Power transmitted by the shaft in kW

R = revolutions per minute of the intermediate shaft

t = specified minimum tensile strength of the material normally between 400 N/mm^2 and 800 N/mm^2 provided percentage elongation on a test length of 5.65 (So)^{0.5} is between 26 and 11.

Note:

1.(So) is the cross-sectional area of the test piece.

2. If the percentage elongation at corresponding minimum tensile strength is not satisfactory the material may not be acceptable for the intermediate shaft, or the propeller shaft as described below).

Propeller shafts protected from sea water by oil lubrication and effective seals, or by a continuous liner should have a diameter not less than that determined by the following formula:-

 $d_p = 100 \text{ k} \{560 \text{ P} / (t+160) \text{ R} \}^{0.333}$

where d_p = diameter of the propeller shaft in mm

P, R and t are the same as for Intermediate shaft, however the value of t in the formula now will be limited to 600 N/mm² although in actuality it might exceed this value and with satisfactory elongation

- K = 1.22 where the propeller is keyless
 - = 1.26 where the propeller is keyed.
- 10.26.3.2 If a non-corrosion resistant propeller shaft is exposed to sea water k will be taken as 1.26 and t will be taken as 400 N/mm² in the above formula so that the formula reduces to: $d_p = 126 \{P/R\}^{0.333}$ where the symbols are as defined above.
- 10.26.3.3 If the propeller shaft is made of a corrosion resistant material and is exposed to sea water the diameter should be determined by multiplying the reduced formula above by a factor A which is less than 1 and its value dependent on its corrosion fatigue resistance property. For stainless steel 316 the A value has been accepted as 0.71. For other materials suitable A values would be considered based on metallurgist's report on any tests.

10.<mark>26</mark>.4 FUEL TANKS ETC.

- 10.26.4.1 Fuel tanks must be of sufficient capacity for 24 hours continuous operation at speed of 6 knots, and should be substantially constructed of steel or other accepted material and should be free standing as opposed to built-in design. Aluminium alloy fuel tanks may be considered if sited in a position separated and removed from the engine. Aluminium should not be used in association with copper pipes or fittings, unless adequate precautions are taken against electrolytic action. The exterior of the tanks should be protected against corrosion from sea water by metal spraying or other means affording protection equivalent to galvanising. Completed fuel tanks and their connections should be capable of withstanding hydraulic pressure to a head of at least 5 metres above the top of the tank. The fuel tank shall have no external load on it.
- 10.26.4.2 Surveyors may accept a maker's certificate for the fuel tank test. The number of joints in a fuel pipe should be kept to a minimum and a shut-off cock must be fitted at each end. Fuel pipes should be of copper or steel. Any shut-off cocks fitted in fuel pipes should be clearly marked to show whether they are OPEN or SHUT.

10.26.5 PROTECTION OF INSTALLATION

10.26.5.1 The engine and its accessories including the fuel tanks, pipes, and fittings should be adequately protected to ensure reliable operation under adverse weather conditions with water spraying over the boat and collecting in the bilges. Attention should be given to the location of alternators fitted to recharge batteries to ensure ease of access and protection from adverse weather or water thrown up by the engine flywheel.

- 10.26.5.2 The engine casing must be fire resistant and should preferably be made of steel; if made of aluminium alloy, glass reinforced plastic or marine plywood they should be lined with materials the insulating properties of which should be equivalent to an A.30 standard.
- 10.26.5.3 Proposed methods of insulating engine casings should take the form of attaching a 25 mm approved A.30 fire insulation to the engine casing sides and tops by steel pins and spring washers, all covered with a vapour barrier and held in place by a wire mesh. The steel pins with a back plate should be glazed to the casing when the engine casing is made of glass reinforced plastic. When the engine casing is made of aluminium the pins should be stainless steel and mechanically attached to the casing. All conduits and penetrations through the casing will need to be plugged to prevent the spread of fire and fumes within the boat. "INTUMESCENT" paint or resins should NOT be used on the inside of glass reinforced plastic engine casings. Casings for air cooled engines, whilst maintaining the necessary fire protection, should allow adequate circulation of the cooling air and any openings in the casings necessary for this purpose should be capable of ready closure in case of fire.
- 10.26.5.4 Cooling water circulating pumps, where fitted, should be self- priming and permit operation for at least five minutes without damage to the pump with the boat clear of the water.

10.26.6 EXHAUST PIPING

- 10.26.6.1 Care should be taken in the siting of the exhaust pipes to ensure that:
 - there are no exhaust system leaks;
 - the exhaust and its lagging runs clear of the bilge water area and that there is little risk of bilge water contacting the engine manifold and exhausts when the boat is in use;
 - exhaust lagging is clean and dry and is provided with suitable protection; and
 - any paint used on engines, manifolds and exhausts does not give off fumes when it is heated.

10.26.7 LUBRICATING OIL

10.26.7.1 Lubricating oil supplied for use in motor lifeboats should be of a grade suitable for the temperatures likely to be encountered in service.

10.26.8SPARE PARTS AND TOOLS

- 10.26.8.1 A box of durable construction containing spares and tools should be supplied with the engine and include the following:
 - one set of inlet and exhaust valves for one cylinder, with springs, washers and cotters;

- one fuel injection nozzle and joint;
- one fuel pipe;
- one set of pressure joints;
- one fuel filter element;
- associated spanners to enable the spares to be fitted;
- screwdriver and pliers; and
- an instruction manual.
- 10.26.8.2 The box should be carried in the lifeboat and contain an engine "Fault location chart" which should indicate the likely faults and how they should be remedied. The chart should be printed in "English" in prominent type on a waterproof card.

10.26.9 MANOEUVRING AND MANNING TRIALS

10.26.9.1 The surveyor should witness manoeuvring and speed trials of a prototype of each motor lifeboat in both the loaded and light conditions. For each subsequent motor lifeboat he should normally witness engine manoeuvring and running trials to satisfy himself that the machinery has been properly installed.

10.27 LIFEBOAT FITTINGS

10.<mark>27</mark>.1 GENERAL

10.27.1.1 The requirements are listed in LSA Code and Schedule 2, Part 1, paragraph 5 of the <u>MSN 1676(M)</u>.

10.27.2 PARTIALLY ENCLOSED LIFEBOATS

10.27.2.1 Partially enclosed lifeboats should comply with LSA Code and Parts 1, 2 and 3 of Schedule 2 of the <u>MSN 1676(M)</u>.

10.27.3 FREE-FALL LIFEBOATS

- 10.27.3.1 At the time of writing these ItoS there were no UK registered fishing vessels that had freefall lifeboats. In the event that future boats are fitted the following should be used.
- 10.27.3.2 Particular attention should be made of the fishing equipment being used and any restriction this would put on free fall launching before accepting the equipment on board.
- 10.27.3.3 These lifeboats and associated launching and recovery arrangements must be MED approved.
- 10.27.3.4 Free-fall lifeboats should comply with LSA Code and Parts 1, 2, 4, 5, 6 and 9 of Schedule 2 of <u>MSN 1676(M)</u> as appropriate.

- 10.27.3.5 Free-fall lifeboats are also required to be capable of a secondary mode of launching by wire, where the primary free-fall launching may not be possible. This alternative launching method must also be tested.
- 10.27.3.6 All occupants of free-fall lifeboats should be provided with an approved inflatable lifejacket, which can be worn during free-fall launching. For safety reasons it is not acceptable to carry inherent buoyant lifejackets during free-fall launching. For this reason, all loose gear should be stowed and secured correctly.

10.28 RETRO REFLECTIVE MATERIAL

- **10.28.1** All survival craft, rescue boats, lifejackets and lifebuoys shall be fitted with retroreflective material in accordance with the relevant.
- 10.29 MARKING

10.29.1 LIFEBOATS

10.29.1.1 As part of certification the boatbuilder is required to permanently mark the boat as required by LSA Code and Schedule 2, Part 1, paragraph 6 of <u>MSN 1676(M)</u> including ship's identification number. After the manufacturer's name or trademark and the date of manufacture the words 'Nominated or Notified Body' should be indelibly marked. As the boats have been produced under the manufacturer's quality approval system it will be for the surveyor undertaking the safety equipment survey of the ship to accept the builders certificate as evidence of satisfactory manufacture and he should carry out such further inspection and operational tests as are required. The surveyor at the ship will verify that the marking of the lifeboat is in accordance with the regulations.

10.29.2 MARKING OF GLASS-REINFORCED PLASTIC BOATS

10.29.2.1 Where, because of the nature of the material used, it is not possible to adopt the conventional methods of "cutting-in or centre punching" the required markings should be engraved in or stamped on plates of metal or plastic which should be secured to the main structure by means of rivets, bolts with ends clenched, or screws with the slots removed by filing. Alternatively, the metal or plastic plates should be secured by means of epoxy adhesives and coated with translucent epoxy resin after fitting. Guidance on any other equally effective method may be sought from a Notified or Nominated Body.

10.29.3 MARKING OF DIMENSIONS

10.29.3.1 Dimensions marked on the lifeboat should be in metric to the nearest centimetre. The surveyor should ensure that the ship's name or radio call sign letters are clearly marked on top of the lifeboat canopy.

10.29.4 ALTERATION OF MARKINGS

10.29.4.1 Once a lifeboat has been marked the marking should not be altered without the permission of the MCA, Nominated or Notified Body.

10.29.5 MARKING INDICATING POSITION ON SHIP

10.29.5.1 In addition, a number should be painted on each bow to indicate the position of the lifeboat on the ship. Lifeboats fitted on the starboard side should be allocated odd numbers, from forward to aft, whilst those on the port side should be allocated even numbers in a similar manner.

10.<mark>30</mark>

10.30.1

10.<mark>31</mark>

10.31.1

EVALUATION, TESTING AND APPROVAL OF LSA AND ARRANGEMENTS

The surveyor or inspector should satisfy themselves that the equipment meets the required standards. This can be done by verifying the equipment is MED approved and/or meets the requirements of a type approval by a recognised organisation where the equipment was fitted prior to MED coming into force.

When in doubt the attending surveyor should contact the appropriate focal point for guidance.

AVAILABILITY AND STOWAGE OF LSA AND SURVIVAL CRAFT

Survival craft must:

- be readily available in case of emergency;
- be capable of being launched safely and rapidly under all conditions;
- be capable of rapid recovery if fulfilling also the requirements for a rescue boat; and
- be so stowed that:
- the marshalling of persons at the embarkation deck is not impeded;
- their prompt handling is not impeded;
- embarkation can be effected rapidly and in good order; and
- the operation of any other survival craft is not interfered with.
- 10.31.2 Where the distance from the embarkation deck to the waterline of the vessel in the lightest operating condition exceeds 4.5 metres, survival craft, except float-free liferafts, shall be capable of being davit-launched with a full complement of persons or be provided with equivalent approved means of embarkation.
- 10.31.3 Survival craft and launching appliances must be in working order and available for immediate use before the vessel leaves port and kept so at all times when at sea.
- 10.<mark>31</mark>.4 Survival craft shall:
 - be stowed:

- So that neither the survival craft nor its stowage arrangements will interfere with the operation of any other survival craft or rescue boat at any other launching location;
- As near to the water surface as is safe and practicable and, in the case of a survival craft other than a liferaft intended for throw overboard launching, in such a position that the survival craft in its embarkation position is not less than 2 metres above the waterline with the vessel in fully loaded condition under favourable conditions of trim of up to 10° and listed up to 20° either way, or at an angle at which the weatherdeck becomes submerged, whichever is less;
- In a state of continuous readiness so that the crew can carry out preparations for embarkation and launching in less than 5 minutes; and
- Fully equipped as required by this chapter.
- Every lifeboat shall be attached to a separate set of davits or approved launching appliance;
- Survival craft shall be positioned as close to accommodation and service spaces as possible, stowed in suitable positions to ensure safe launching, with particular regard to clearance from the propeller. Lifeboats for lowering down the vessel's side shall be stowed with regard to steeply overhanging portions of the hull, so ensuring, as far as practicable, that they can be launched down the straight side of the vessel. If positioned forward, they shall be stowed abaft the collision bulkhead in a sheltered position on suitably strengthened davits;
- The equipment, arrangements and method of launching and recovering of rescue boats shall be approved taking into account the weight of the rescue boat including its equipment and 100% of the number of persons it is certificated to carry, the construction and size of the rescue boat and its position of stowage above the waterline in the vessel's lightest operating condition;
- Launching and embarkation appliances and free fall lifeboats shall comply with the requirements of the IMO International Life-Saving Appliance Code;
- The liferafts must be so stowed:
 - o as to be readily available in case of emergency;
 - in such a manner as to permit them to float free from their stowage, inflate and break free from the vessel in the event of its sinking;
 - o davit-launched liferafts need not float free;
 - lashings, if used, should be fitted with an automatic (hydrostatic) release system of an approved type;
- The MCA, if it is satisfied that the constructional features of the vessel and the method of fishing operation may render it unreasonable and impractical to apply particular provision of this paragraph, may accept relaxations from such provisions, provided that the vessel is fitted with alternative launching and recovering arrangements adequate for the service for which it is intended. Alternative launching and recovery arrangements, which the MCA has allowed under this subparagraph, shall be notified to the International Maritime Organization for circulation to other Parties.

10.<mark>32</mark>.1

10.33.1



Suitable arrangements shall be made for embarkation into the survival craft which shall include:

- at least one ladder, or other approved means, on each side of the vessel to afford access to the survival craft when waterborne except where the MCA is satisfied that the distance from the point of embarkation to the waterborne survival craft is such that a ladder is unnecessary. This ladder to have safe securing and access arrangement;
- means for illuminating the stowage position of survival craft and their launching appliances during preparation for and the process of launching, and also for illuminating the water into which the survival craft are launched until the process of launching is completed, the power for which to be supplied from the emergency source;
- arrangements for warning all persons on board that the vessel is about to be abandoned; and
- means for preventing any discharge of water into the survival craft.

10.33 OPERATIONAL READINESS, MAINTENANCE AND INSPECTIONS

Before the vessel leaves port and at all times during the voyage, all life-saving appliances, including the spare ones, must be in working order and ready for immediate use.

10.34 MAINTENANCE

- 10.34.1 Instructions for on-board maintenance of life-saving appliances shall be provided and maintenance should be carried out accordingly;
- 10.34.2 The MCA may accept, in lieu of the instructions required by 10.38.1, a shipboard planned maintenance programme.

10.35 SERVICING OF LSA

- 10.35.1 Rigid inflated rescue boats which form part of the ships' Life-Saving Appliances are normally required to be serviced annually, and every effort should be made to ensure that this is carried out. When, however, it is clearly impracticable to comply with this requirement, the servicing may be deferred for a period not exceeding 5 months.
- 10.35.2 At every bi-annual servicing of a rigid inflated rescue boat a 10% overload static load test should be carried out with the rescue boat suspended from its lifting hook or bridle in accordance with the manufacturer's approved servicing instructions.
- 10.35.3 An "approved service station" is one which has been formally appointed by the manufacturer of an approved type of rigid inflated rescue boat and has been accepted by the Secretary of State. It has certificated personnel who have been trained to undertake servicing and repairs, and it carries genuine spares and is

kept fully informed of the current servicing procedures by the approved manufacturer.

- 10.35.4 Detailed lists of names and addresses of the manufacturers of approved rigid inflated rescue boats and their currently appointed service stations located in the United Kingdom are given in the relevant Marine Guidance Note.
- 10.35.5 Shipowners and masters are respectfully reminded that it is an offence to carry a rigid inflated rescue boat, which is known to be defective, or which has not been serviced at the intervals prescribed by the Regulations.

10.36 ON BOARD TRAINING AND INSTRUCTIONS

10.<mark>36</mark>.1

On-board training in the use of the vessel's life-saving appliances, including survival craft equipment, must be given as soon as possible but not later than two weeks after a crewmember joins the vessel. However, if the crew member is on a regularly scheduled rotating assignment to the vessel, such training must be given not later than two weeks after the time of first joining the vessel;

- 10.36.2 Instructions in the use of the vessel's life saving appliances and in survival at sea shall be given at the same intervals as the drills. Individual instruction may cover different parts of the vessel's life-saving system, but all the vessel's life-saving equipment and appliances shall be covered within any period of two months. Each member of the crew should be given instructions which shall include but not necessarily be limited to:
 - Operation and use of the vessel's inflatable liferafts, including precautions concerning sharp objects;
 - Problems of hypothermia, cold water shock, first-aid treatment for hypothermia and other appropriate first aid procedures;
 - Special instructions necessary for use of the vessel's life-saving appliances in severe weather and severe sea conditions.

10.36.3 On-board training in the use of davit-launched liferafts must take place at intervals of not more than four months on every vessel fitted with such appliances. Whenever practicable this shall include the inflation and lowering of a liferaft. This liferaft may be a special liferaft intended for training purposes only, which is not part of the vessel's life-saving equipment; such a special liferaft shall be conspicuously marked.



TRAINING MANUAL

A training manual shall be provided in each crew messroom and recreation room or in each crew cabin. The training manual, which may comprise several volumes, shall contain instructions and information, in easily understood terms illustrated wherever possible, on the life-saving appliances provided in the vessel and on the best methods of survival. Any part of such information may be provided in the form of audio-visual aids in lieu of the manual. The following shall be explained in detail:

- Donning of lifejackets and immersion suits, as appropriate;
- Muster at the assigned stations;
- Boarding, launching, and clearing the survival craft and rescue boats;
- Method of launching from within the survival craft;
- Release from launching appliances;
- Methods and use of devices for protection in launching areas, where appropriate;
- Illumination in launching areas;
- Use of all survival equipment;
- Use of all detection equipment;
- With the assistance of illustrations, the use of radio life saving appliances;
- Use of drogues;
- Use of engine and accessories;
- Recovery of survival craft and rescue boats including stowage and securing;
- Hazards of exposure and the need for warm clothing;
- Best use of the survival craft facilities in order to survive;
- Methods of retrieval, including the use of helicopter rescue gear (slings, baskets, stretchers), breeches buoy and shore life-saving apparatus and vessel's line-throwing apparatus;
- All other functions contained in the muster list and emergency instructions;
- Instructions for emergency repair of the life saving appliances;
- On vessels of less than 45 metres in length (L) the MCA may permit relaxation of certain requirements. However, appropriate safety information should be carried on board; and
- Instruction on use and operation of fire appliances.

10.38 PERIODIC SURVEYS OF LIFE SAVING APPLIANCES

10.<mark>38</mark>.1 GENERAL

10.38.1.1 When carrying out a survey, surveyors should take the opportunity to impress upon masters and owners or their representatives the necessity and their statutory obligations to frequently inspect all life-saving appliances and maintain them in accordance with the "Instructions for On-board Maintenance".

10.<mark>38</mark>.2 LIFEBOATS

10.38.2.1 METHOD OF SURVEY

10.38.2.1.1 When ships are under survey for a FVC the lifeboats should be lifted clear of the chocks and carefully examined both inside and outside.

10.38.2.2 BUILT-IN BUOYANCY AIR CASES

Where lifeboats are fitted with built-in buoyancy compartments the surveyor should, after careful examination, carry out such tests, which may include tests by air pressure, as he considers necessary. A pressure of 10 kgf/m² is sufficient for this purpose and should not be exceeded. In order to avoid overstressing the compartments, it is strongly recommended that the pressure should be applied by means of a hand pump in conjunction with a suitable calibrated mercurial U-tube for enabling small differences in pressure to be read. Leakage where indicated, may be located by the application of soapy water to the seams.

10.38.2.3 SOLID BUOYANCY

10.38.2.3.1

10.38.2.2.1

Where solid buoyancy is fitted it will normally be unnecessary, to remove this for inspection at each survey unless the surveyor has reason, because of the condition or general appearance of the boat, to suspect defects. It should be noted that some of the earlier types of solid buoyancy, e.g. polystyrene, were not fully oil resistant and were subject to damage from oil leakage in motor propelled lifeboats. Partial opening up should be required to facilitate examination of such material and any defective portions should be replaced by an accepted oil resistant material which is not chemically incompatible with existing material.

10.38.2.4 LIFTING HOOKS

10.38.2.4.1

Careful attention should be paid to the condition of lifting hooks and their connection in all lifeboats. Where signs of corrosion are evident in the lifeboat lifting connections the lifting hooks should be removed and one or more lifting hook connection bolts through keel backed out for examination. Where disengaging gear is fitted surveyors should carry out and witness tests in accordance recognised procedures.

10.38.2.5 STEEL LIFEBOATS

10.38.2.5.1

Rust and scale should be removed from steel lifeboats before any detailed inspection is carried out.

10.38.2.6 ALUMINIUM ALLOY LIFEBOATS

10.38.2.6.1 A

Aluminium alloy lifeboats should be carefully examined for condition, particularly behind the skates, their securing wires and also gripe wires where metals other than aluminium may have been in contact with the hull of the lifeboat. Surveyors should pay special attention to the riveting of aluminium alloy as in some cases rivets of NR6 material were used which have proved to be unsatisfactory. Where re-riveting is found to be necessary only rivets of NR5 material should be used.

10.38.2.7 GLASS-REINFORCED PLASTIC LIFEBOATS

Glass-reinforced plastic lifeboats should be carefully examined for fractures particularly in garboard attachments of built-in buoyancy and the junction of thwarts and side seats. Fractures may also have occurred in the horizontal and vertical surfaces of side buoyancy and in the gunwale, usually at positions approximately one-quarter of the length of the lifeboat from the bow or stern.

10.38.2.7.1

Repairs should be carried out as recommended by the lifeboat manufacturer to the satisfaction of the surveyor. If repairs are extensive a 25% overload strength test may be necessary on completion

10.38.2.8 WOOD LIFEBOATS

10.38.2.8.1

WOOD LIFEBOATS Wood lifeboats are to be carefully examined for timber decay, and if found, the

10.<mark>38</mark>.2.9 REPAIRS

10.38.2.9.1 Where defective portions are found in lifeboats, surveyors should refer to the relevant paragraph of these Instructions and ensure that repairs are effected with the materials and in accordance with the procedure detailed therein. All repairs, renewals, etc. to the hulls of fibre-reinforced plastic lifeboats should be carried out by experienced laminators.

affected timber should be cut out well beyond the affected area and replaced.

10.38.2.10 LOWERING OF LIFEBOATS AT SURVEY

10.38.2.10.1 As many lifeboats as possible should be lowered into the water at the time of survey to test not only the watertightness of the lifeboats but also the operation and efficiency of the lowering gear.

10.38.3 MOTOR AND OTHER MECHANICALLY PROPELLED LIFEBOATS

10.38.3.1 RESCUE BOATS ON FISHING VESSELS OF 24M TO LESS THAN 45M.

- 10.38.3.1.1 A rescue boat should be fitted to all new Fishing Vessels and for those at the early stage of Construction on 29/6/18.
- 10.38.3.1.2 For existing vessels all exemptions should be reconsidered by a panel review comprising of the Fishing Vessel Consultant Surveyors. The review is not to wait to the renewal, because it would then not allow the operator to plan for the fitting at the survey. It should be noted that just because space does not appear to be available in its current form does not mean it is not practical to retrofit one. Platforms can be constructed, and novel means of stowage can be considered, where there is a will and need to fit one.
- 10.38.3.1.3 Where an exemption is considered, then the conditions in the MSN should be applied, including the near SAR facilities and only where the "operation of the vessel in areas not susceptible to heavy weather or the seasonal characteristics of the operation, such provision is unnecessary".
- 10.<mark>38</mark>.3.1.4 The conditions were amended as follows:

Limiting Area of operation to:

 near availability of SAR response – No more than 60nm from shore where helicopter SAR assets are available. [Vessel crew should be limited to capacity of one SAR helicopter in area of operation.][A Sikorsky 92 capacity is 8 persons, has a Radius of action of 250 miles, a max speed of 165 knots (cruising 145) and a AW189 capacity is 6 persons with a Radius of action of 190 miles, a max speed of 169 knots and cruising of 145. Each Helicopter will take at least an hour to get to a FV 150 miles out (from the Helo base, not land). In addition, when on station at that range the search time will be very limited. Therefore, the distance is reduced to 60nm.]

- Availability of meteorological warnings If vessel only has VHF reception 30nm from shore, otherwise 150nm if these can be received by NAVTEX, SATCOM C or HF radio (reverting to the SAR limit) and if the vessel is also fitted with long range AIS. [Vessel must be GMDSS compliant for Area A2]
- Vessel not to enter ILLC defined Winter Seasonal Zones during the relevant period.
- Where the operation of the vessel is in areas not susceptible to heavy weather or the seasonal characteristics of the operation, such provision is unnecessary. This should be sheltered conditions in winter, limited to not more than 60 miles or 6 hours from a safe haven, whichever is the lesser (the 6 hours corresponds to when a weather forecast would state a storm is imminent).

OR characteristics of the operation

• Seasonal characteristics of the operation – 'operating' means catching or catching and processing fish or other living resources of the sea without prejudice to the right of innocent passage in the territorial sea and the freedom of navigation in the 200 mile exclusive economic zone;

Outfit

- the ship is arranged to allow a helpless person to be recovered from the water; the vessel shall be fitted with a suitable and efficient means of retrieving unconscious persons from the water.
- the crew are provided with immersion suits
- additional life buoy and line stowed aft.

Crew

- A detailed risk assessment is available for any work activity which requires a crew member to be stationed with in a zone one metre from the deck edge.
- The crew should be properly trained and will give a practical demonstration of its use in the retrieval of a man overboard, being a dummy or manikin of similar size and weight to an unconscious person.
- The demonstration should be to the satisfaction of the surveyor.
- The vessel must be capable of carrying no more than 6 crew. It must be demonstrated that the <u>Fishing Vessels (Working Time: Sea-fishermen)</u> <u>Regulations 2004 No.1713</u> can be complied with.

10.38.3.2 MOTOR LIFEBOATS AND RESCUE BOATS

10.38.3.2.1

The machinery of motor lifeboats and rescue boats should be inspected. Engine running and manoeuvring trials should be carried out at each survey. The engine need only be dismantled for examination if the surveyor has reason to doubt its condition and performance. The survey should include the fuel tanks, their filling and relief arrangements, the fire extinguishing appliances and, where fitted, the searchlight, the radio battery, etc.

10.<mark>38</mark>.3.3 10.38.3.3.1

MECHANICALLY PROPELLED LIFEBOATS

Propelling gear should be inspected at each survey and tried preferably afloat, for ahead and astern operation.

10.<mark>38</mark>.3.4 TOTALLY ENCLOSED LIFEBOATS

10.38.3.4.1

In addition to thither tests required for totally enclosed lifeboats, when a totally enclosed lifeboat is in the water the opportunity should be taken to run the engine to full operating temperature to see if fumes develop from the exhaust system. Surveyors should check that:

- there are no exhaust system leaks;
- there are no oil or diesel leaks and the engines are clean;
- the exhaust and its lagging runs clear of the bilge water area and that there • is little risk of bilge water contacting the engine manifold and exhausts when the boat is in use;
- exhaust lagging is clean and dry and is provided with suitable protection;
- bilges are kept dry and clear of oil; and
- any paint used on engines, manifolds and exhausts does not give off fumes when it is heated.

10.<mark>38</mark>.3.5 **OUTBOARD MOTORS FOR RESCUE BOATS AND INFLATED BOATS**

10.38.3.5.1

10.38.4.2.1

Surveyors should inspect and conduct running trials on outboard motors for rescue boats and inflated boats at each survey. Servicing of outboard motors is dependent upon the amount of use they receive, but in any case should be serviced annually. A record of the servicing should be kept. The fire extinguishing

appliances and arrangements for the stowage of petrol should also be examined

10.38.4 LIFEBOAT EQUIPMENT AND FITTINGS

10.<mark>38</mark>.4.1 GENERAL

10.38.4.1.1 All lifeboat equipment and fittings should be checked for condition and compliance with the Regulations. The surveyor should ensure that each item meets the requirements set out in the relevant paragraphs of these Instructions.

10.<mark>38</mark>.4.2 MASTS AND SAILS, ETC.

Masts and sails where provided should be rigged, exposure covers were required should be placed in position, rudder and tiller shipped and grab lines and their means of attachment to the boat examined.

10.<mark>38</mark>.4.3 SKATES

10.38.4.3.1 Skate securing arrangements where fitted should be examined and their means of release from the lifeboat tested for satisfactory operation. The shell of the boat in way of the skates should be carefully examined.

10.38.4.4 WATER AND RATION TANKS

Fresh water tanks and ration tanks should be examined at each survey and their markings renewed if necessary. Filling plugs and aperture covers should be well fitting and properly rubbered to prevent the entry of contaminants. Portable plastic water containers should be examined to ensure that the dipper is secured by its lanyard or chain to the inside of the larger of the two caps. The surveyor should be satisfied that fresh water tanks are clean and that the water is changed frequently.

10.<mark>38</mark>.4.5 RATIONS

Should be examined for their condition and those defective should be replaced. Surveyors should ensure that the scale of rations is provided in accordance with the 1999 Regulations. (See paragraph 10.16).

10.38.4.6 RADIO EQUIPMENT

10.38.4.6.1

10.38.4.5.1

10.38.4.4.1

The examination and testing of all lifeboat radio equipment will be carried out by a Radio Surveyor as part of the Safety Radio Certificate survey if applicable or upon request. MCA surveyors should ensure that battery charging arrangements for the two-way radio telephone sets are in order and that stowage arrangements for radar transponders (SARTs) are satisfactory. The float free arrangements for the Satellite Emergency Position Indicating Radio Beacons (EPIRB) are in good condition and working order. Hydrostatic release units used on EPIRBs should be serviced or replaced in the same way as those required for liferafts.

10.<mark>38</mark>.4.7 SEAT BELTS

10.38.4.7.1 Surveyors should ensure that seat belts and their fastenings together with their anchor points and head restraints, where fitted, are in good serviceable condition.

10.38.5 INFLATABLE LIFERAFTS, RIGID INFLATED RESCUE BOATS AND INFLATED BOATS

10.38.5.1 GENERAL

10.38.5.1.1 Requirements are contained in MSN 1871, Chapter 7; in MSN 1872, Chapter 7; and in MSN 1873, Chapter 7.

10.38.5.1.2 The survey of inflatable liferafts and boats and their equipment including any provisions should be carried out at approved service stations. Surveyors should ensure that inflatable liferafts and boats are serviced and tested strictly in accordance with the procedure set out in the relevant maintenance manuals. Particular attention should be given to the packing and sealing of inflatable liferafts in their containers (or valises where still used and accepted).

10.38.5.2 STOWAGE OF INFLATABLE LIFERAFTS

Careful consideration should be given to the siting of inflatable liferafts for ease of launching, particularly in those Classes of ships where they must be stowed in position such that they can be readily transferred to the water on either side of the ship. Whilst it is considered that the practice in small ships of stowing boats and

10.38.5.2.1

liferafts alongside the accommodation is generally most desirable the concentration of these appliances in small areas is to be avoided if possible. It is impracticable to lay down precise instructions as to where liferafts should be sited but in small ships, generally, the liferafts should not be placed alongside the boat(s). Where more than one liferaft is provided they should be distributed on each side of the ship and so sited, fore and aft, that an incident (fire or collision) is unlikely to make all liferafts inaccessible.

10.38.5.3 QUICK RELEASE OF LIFERAFTS

10.38.5.3.1 The surveyor should examine the arrangements for affecting quick release of each liferaft from its stowage.

10.38.5.4 STOWAGE OF INFLATED AND RIGID INFLATED RESCUE BOATS

Surveyors should be guided by these Instructions in respect of the stowage arrangements for inflated and rigid inflated rescue boats and should ensure that the securing arrangements are adequate in every case, and are not damaging the craft.

10.38.6 LIFEBOAT AND RESCUE BOAT DAVITS, LIFERAFT LAUNCHING APPLIANCES, WINCHES, LOWERING AND RELEASE GEAR

10.<mark>38</mark>.6.1 GENERAL

10.38.5.4.1

10.38.6.1.1

Surveyors should check that arrangements for operational readiness, maintenance, shipboard periodic inspections and servicing manuals are in place. Ships officers and crew should be aware of the Training Manuals and Instructions for on-board maintenance for these appliances including release hooks and that log records of inspections and maintenance are kept up-to-date.

10.38.6.1.2 The lifeboat davits, the lowering gear including blocks and falls, the fairleads, the tricing gear, the bowsing-in tackles and the boat lowering winches should be inspected at each survey. Particular attention should be given to parts of the davits structure and wire rope falls which are normally out of sight and to the security of the attachment of the ends of the falls. In the case of a limited number of specialised designs of davits which requires some structure to be made, it should be arranged that such thorough examination be made at intervals not normally exceeding five years. It should be seen that sufficient attention has been given to the lubrication of the working parts and that no grease nipples have been removed or painted over.

- 10.38.6.1.3 Turning out and boat lowering tests or proof tests should be witnessed, and the remote control of pumps discharging in way of lifeboats and liferafts, and the limiting devices to prevent the overloading of the falls in gravity davits should be tested by the surveyor at each survey.
- 10.38.6.1.4 While turning out and boat lowering the release gear should be tested for on-load simultaneous release (if fitted) when the keel of the boat is near the water. After

this is demonstrated to be satisfactory, the boat can be lightened if it was weighted, and hooked up again to be hoisted by the winch within its designed SWL. It should be specially noted that the winch is normally designed to hoist a lifeboat with its launching crew only and that hoisting with additional persons or load could damage the winch and be dangerous for persons in the boat. It should also be specially noted that following a satisfactory release of the boat from the hooks it is also essential that re-attachment of the falls to the hooks and proper locking of the hooks and the operating lever, as advised by the manufacturer in the instruction manual, is carried out. Many accidents can be attributed to the eagerness to bring the boat back on board after a satisfactory boat drill and overlooking the importance of relocking properly. It may be that a fault in the release gear develops after release so that it cannot be re-set and locked properly in which case the hooks should not be used until the fault has been rectified. The boat can be hoisted back on board by using the maintenance lugs and pennants. Once the boat can be safely handled by the shipboard winch, the off-load release test may be carried out by lowering the boat in water until it is waterborne and then operating the release mechanism. Note that the precautions and checks for resetting and re-locking of the hooks and the operating lever is applicable after every release whether on-load or off-load or whether the boat is loaded or light.

10.38.6.5 WIRE ROPE FALLS

10.<mark>38</mark>.6.5.1

Wire rope falls should be renewed every five years. If on inspection on the davits , those parts of the falls that have been exposed to the weather are found to have deteriorated to an extent likely to affect their strength the surveyor should require the falls to be renewed. Where davits, which employ a single length of wire rope fall, middled between the davits with the two ends attached to the winch, are fitted, reversal can be achieved by cutting the falls at the centre of its length and splicing the ends which were originally on the winch barrels with thimbles to form eyes. The eyes can then be joined with a suitable shackle and the pin fitted with a satisfactory locking arrangement. Compliance with Schedule 6, Part 1, paragraphs 4(3) and 4(4) of <u>MSN 1676(M)</u> as appropriate is required in respect of the spliced connection and surveyors should be satisfied with the components used.

- 10.38.6.5.2 It may be that the reversal of the falls cannot be carried out safely or conveniently as required and in such event the MCA has recognised the equivalent of renewing the falls after four years instead of five provided thorough inspection does not reveal any deterioration. Shipowners requiring the benefit of such equivalence should contact the nearest Marine Office. Surveyors attention is also drawn to MSIS 23 Part 2, paragraph 2.4 of MCA Survey and Certification Policy Instructions.
- 10.38.6.5.3 There are many kinds of stainless steel, only the very best quality is likely to have a service life greater than five years. Stainless steel falls are subject to heavy pitting in inside areas where this is not easily visible by simple outside inspection and if no service life is recommended by the manufacturer for marine use,

stainless steel falls should be treated no differently than galvanised steel falls for renewal purposes.

10.38.6.6 **WINCHES**

10.<mark>38</mark>.6.6.1

A proportion of boat winches should be opened up for thorough examination at each survey, the programme for this work should be arranged in such a manner that every winch is opened up for examination at intervals of not more than four years.

- 10.<mark>38</mark>.6.6.2 Where winches are used for lifeboat/passenger launches or any other highly worked survival craft or work boat the winches should be opened up for thorough examination every two years. In addition, on all winches which are fitted with a roller ratchet mechanism the opportunity should be taken to renew the roller retaining springs at these examinations.
- 10.<mark>38</mark>.6.6.3 There have been reports of some hand brake failures during tests of this type of winch. The winch is used normally in conjunction with a single arm davit for handling rescue boats. The winch was originally type approved by the MCA in 1979 for a maximum load of 500 kg and the design is such that an externally fitted spring tension holds the hand brake in effective position. The failures reported are for winches which have been more recently manufactured and accepted for loads higher than 800 kg.
- 10.38.6.6.4 Investigations of failure suggest that the spring tension is reduced over time until the hand brake is no longer able to hold a heavy load. In each case the replacement of the spring rectified the fault. The MCA has therefore informed the manufacturer that such a design of winch will no longer be accepted for UK Registered Vessels for a working load over 500 kg.
- 10.38.6.6.5 For vessels which already have these winches fitted for loads higher than 500 kg acceptance will be continued on condition that:
 - the spring is inspected at least once a week if the equipment is not in use, and inspected prior to commencement of any operation, and
 - sufficient spare springs are carried on the vessel to replace any faulty or suspected spring.
- 10.<mark>38.</mark>6.6.6 Although no adverse reports have been received for the winches where the working load is 500 kg or less, the winch operators are nevertheless advised to inspect the external spring regularly and carry spares.
- 10.38.6.6.7 Winches used for any type of survival craft, work boat or launch should, if fitted with a roller ratchet mechanism, have such mechanisms regularly maintained. The ratchet mechanisms should never be packed with grease; a light non-solidifying grease or light oil should be lightly smeared on the mechanisms to assist easy movement and to prevent the onset of corrosion.

- 10.38.7 LOWERING DEVICES OTHER THAN DAVITS FOR LIFEBOATS, RESCUE BOATS, INFLATED BOATS, CLASS C BOATS OR BOATS
- **10.38.7.1** Surveyors should be satisfied with the condition of all parts of the devices and its fittings, and with the lowering and recovery gear including the purchase, blocks, topping lift and guys. Turning out and boat lowering tests would be witnessed at each survey.

10.38.8 UNDER-STRENGTH DAVITS OR OTHER LAUNCHING DEVICES FOR LIFEBOATS, RESCUE BOATS, INFLATED BOATS, CLASS C BOATS OR BOATS AND LAUNCHING CREWS

10.<mark>38</mark>.8.1 GENERAL

- 10.38.8.1.1 In a case where the boat or the means of launching is not of sufficient strength for the boat to be lowered safely into the water when loaded with its full complement of persons and equipment required by the Regulations the davits or other means of launching shall be conspicuously marked with a RED BAND 150 millimetres wide painted on a white background.
- 10.38.8.1.2 The MCA considers that the proper number of men for a launching or recovery crew when the device is "RED-BANDED" is two. Shipowners, Masters, Officers and Seamen of merchant ships, and Owners, Skippers, Mates and Crews of fishing vessels are, therefore, asked to note that this number should never be exceeded.
- 10.38.8.1.3 A notice should be attached to each relevant set of davits or other device stating, "Lower or recover with two man crew only".
- 10.38.8.1.4 In the case of a launch/recovery device for an inflatable boat, although in certain circumstances the boat is not required to be fitted with an engine, an allowance is made in all cases for the weight of an engine and its fuel of at least 60 kgs in case one is fitted at a later date.

Note: Lifeboat Davits must be of sufficient strength to launch the boat and full complement. Rescue boat davits must be of sufficient strength to safely enable recovery of the rescue boat, it's equipment and full complement of persons.

10.39 LIFEBOAT AND RESCUE BOAT DISENGAGING GEARS AND SIMILAR ARRANGEMENTS

10.39.1 GENERAL CONDITIONS OF ACCEPTANCE OF DISENGAGING GEARS

10.39.1.1 Requirements are contained in MSN 1873, Chapter 7.

- 10.39.1.2 In general the equipment should be MED approved. If not MED approved, such as on a Non-European flag-in it must be still be type approved by a recognised organisation to at least the same standards used for MED approval.
- 10.39.1.3 The statutory requirements for lifeboat and rescue boat disengaging gears are contained in Schedule 2, Part 1, paragraphs 8.1 to 8.7 of <u>MSN 1676(M)</u>.

MSC Circulars 317,320,1392 and 1393 gives guidance on the future requirements for changing over existing davit launched lifeboat on-load release hooks into a "release and retrieval system " that comply with the requirements of the amendments to 4.4.7.6 of the LSA Code.

10.<mark>39</mark>.2 FALL PREVENTER

- 10.39.2.1 At all times that the equipment is being used the fitting of a fall preventer mechanism should be used in accordance with IMO and relevant MCA guidance.
- 10.39.2.2 Unless fitted with a release hooks complying with MSC. Circ 320 than fall preventers should still be used.

10.39.3 TESTS FOR DISENGAGING GEARS

10.39.3.1 PROOF TESTING OF PRODUCTION HOOKS

10.39.3.1.1 Disengaging gears for lifeboats and rescue boats shall be proof tested.

10.39.3.2 TOWING AND DISENGAGING TESTS

- 10.39.3.2.1 The 10% overload "on-load" release test need only be carried out once, either at the lifeboat and rescue boat builders works or when installed on the ship.
- 10.39.3.2.2 Other annual and five-year testing should be carried out in accordance with relevant testing procedure. (MGN560 at time of writing).

10.39.4 MARKING OF EMERGENCY HAND RELEASE

10.39.4.1 In all lifeboats and rescue boats fitted with disengaging gear the position of the emergency hand release should be clearly indicated.

10.39.5 OPERATING INSTRUCTIONS

10.39.5.1 A card containing simple operating instructions should be supplied to every lifeboat and rescue boat fitted with disengaging gear, for the guidance of officers and lifeboatmen.

10.39.6 LUBRICATION

10.39.6.1 Only grease which will function satisfactorily over a wide temperature range should be used to lubricate disengaging gear.

10.39.7 INSTALLATION AND INSPECTION OF DISENGAGING GEARS

10.39.7.1 In dealing with the installation of disengaging gears surveyors should satisfy themselves that such gears comply in all respects with the specification referred to in the certificate. Fitting should be carried out strictly in accordance with the accepted arrangements and the gear should be subjected to the programme of tests detailed in MSN 1803.

10.39.8 TESTS AT PERIODIC SURVEYS

- 10.39.8.1 At the periodic surveys of MCA on board ships, disengaging gears should be tested to ensure the simultaneous release when the lifeboat or rescue boats are waterborne. Where the rods are found to be defective in certain standard type disengaging gear comprising part rod, part chain release, they should be replaced with all chain release. When the surveyor is satisfied that the simultaneous release mechanism is in good working order it should be further tested with the lifeboat suspended just above the water to ensure that release does not take place until the lifeboat is waterborne.
- 10.39.8.2 Surveyors should be satisfied that the safety pin or safety catch and clip on the release lever are effective. Every opportunity should be taken to impress upon masters and officers the need for ensuring that the lifting hooks are fully engaged with the lower fall blocks and that the release lever safety pin or safety catch and clip are in the safe position before lifeboats are recovered and stowed after boat drills, lowering tests, etc.

10.39.9 STATUTORY PROOF TESTING OF DISENGAGING GEARS

- 10.39.9.1 The Merchant Shipping (Life-Saving Appliances for Ships other than Ships of Classes III to VI(A)) Regulations 1999 require (among other things) that "at least once every 5 years rescue boats and lifeboats shall be turned out and lowered when loaded with weights to simulate 1.1 times the total mass of the lifeboat or rescue boat when loaded with its full complement of persons and equipment and whenever the release gear is overhauled".
- 10.39.9.2 Such a test is intended to prove the adequacy of every part of the fully loaded launching system such as davits, winches and their foundations; falls, blocks, connecting loose gear such as shackles, rings; release gear hooks and their connections to the boat etc. In addition, it tests the tricing and bowsing arrangements and load distribution on the boat itself as would be imposed in a real evacuation situation.
- 10.39.9.3 Some shipowners have approached the MCA for guidance in conducting this test safely. The MCA has therefore consulted the relevant experts in the field and one method of carrying out the test safely is described in this paragraph.

- 10.39.9.4 The shipowner must look ahead and plan such tests. The launching device comprises many specialised components which require regular inspection, maintenance, replacement, overhaul etc. by specially trained personnel which should best be completed before the test. There may be a large number of boats to test (e.g. for large passenger ships), so a regular programme of tests spread over five years to cover all the boats may be essential.
- 10.39.9.5 Having decided to test a particular boat, preliminary inspection of key parts likely to be stressed during the test needs to be made. If specialised help from manufacturers is not available, the ship's Chief Engineer (or his delegate) should carry out such an inspection following the manufacturer's manuals and general engineering principles. In addition, ship's LSA maintenance logs are to be scrutinised to confirm evidence of regular maintenance and history of any persistent problem or major fault.
- 10.39.9.6 It is also necessary to carry out an audit of certificates on board for falls, blocks, loose gear, davits, winches, release gear hooks, lugs etc. to confirm compliance with proof load requirements and identification of correct and adequate gear. Having been satisfied by these preliminary inspections and checks that a test can go ahead, a shore or floating crane with an SWL rating of at least 2.2 times the fully loaded boat weight (to absorb shock loads in emergency) is to be arranged for assisting in the test with safety.
- 10.39.9.7 The test is to be carried out by accredited service personnel with a ship's officer in charge (OIC) and witnessed by an authorised person. The OIC is in charge of the test at all times and should brief those carrying out the test on what is required. The authorised person should take no part in the test and should not be the OIC. The authorised person may be an MCA surveyor, a Classification Society Surveyor appointed by MCA, or other persons authorised by MCA to witness such tests. If the authorised person is not an MCA surveyor, then the individual concerned will require a letter of appointment from Survey Branch in MCA headquarters. MCA authorised Class Societies should be aware of these procedures as this will have been given as part of a general authorisation.
- 10.39.9.8 This is notwithstanding that MCA surveyors may be present to witness the tests, or component manufacturers' representatives may be present having overhauled or repaired any item, or that a dockyard foreman may be present who has arranged to supply labour, weights and the crane. Before commencing any operation, agreed signal or verbal concurrence from the PIC needs to be obtained and similarly any actual or potential problems must be quickly brought to his attention for resolution.
- 10.39.9.9 At a suitable time the procedure should commence with lowering of the empty boat to the embarkation deck and checking of tricing arrangement and the winch brake effectiveness. The bowsing tackle should then be set up and tightened from the shipside for this test (and not from within the boat as is normal) and the tricing pendants removed. (For directly loaded and launched boats the effectiveness of

brake is to be tested by partly lowering the empty boat and then moving it back to the stowed position for loading.)

10.<mark>39</mark>.9.<mark>10</mark>

The boat should then be connected to the crane via transportation or maintenance lugs (which should have been proof load tested to at least 2.2 times the fully loaded boat), ensuring that the crane main wires can be disconnected from the ship without having to climb into the boat when the loading is completed. A load cell should preferably be incorporated in the crane connection wire to verify the correct loading. The crane should then gently take up the load of the boat, causing the falls to be visibly and slightly slack.

- 10.39.9.11 The loading of the boat then should commence with the agreed and predetermined mode of loading (e.g. pellet bags, weights, waterbags etc. as available and suitable. Note: large waterbags have been known to cause instability during lowering and braking operation). The load should be distributed evenly simulating an actual body load of persons as nearly as practicable taking into account possibility of load shift and damage to the boat.
- 10.39.9.12 When the loading is completed (either determined by calculation or verified by the load cell), the boat weight should be gently transferred to the falls and crane wires made minimally but visibly slack. The boat should also be seen to be held against the shipside by the bowsing tackles and this position is to be held and observed for at least 5 minutes with further inspection of shipboard structural parts of the system under stress for integrity. Afterwards crane connections are to be slackened and pulled on board the ship (either by a boat hook, or pre-connected rope etc) and disconnected. The crane main wires should then be hoisted and cleared away and the short wire ends connected to the boat should be thrown back on the boat or put there by a boat hook.




figure 10.1

- 10.39.9.13 The fully loaded boat, without any persons, should then be gently bowed out from the ship side (see 10.39.9.9 above for special bowsing tackle set up for this test only) until falls are vertical and then the shipside ends of the bowsing gear are to be disconnected and the loose ends put back on the boat.
- 10.39.9.14 The fully loaded boat, without any person, should then be lowered away (observing look-out and other precautions) until maximum lowering speed is reached when the hand brakes should be suddenly applied and tested for effectiveness, followed by thorough visual inspection of heavily stressed parts of the davit and winch structures, including welded areas on deck. When satisfied, the boat should then be gently lowered further by easing the winch hand brake until the boat reaches a position where its keel is just touching (or clear of) the water, where the boat should be stopped. Operating crewmen should then approach the boat under test by another boat and enter it observing relevant precautions with the intention of testing of the on-load release gear. (Note: If the boat has been lowered past this position and it is necessary to hoist it back even by a small amount, the crane is again to be connected up to assist, as the

shipboard winch is designed (under SOLAS and MS Regulations) to hoist a lifeboat with only the handling crew and not with full load.)

- 10.39.9.15 The crew having entered the boat should inspect the release hooks for proper closure (as in the manual) and the fixing arrangements to the relevant boat areas. If satisfactory, the release gear should then be operated according to the instructions manual, to test the on-load mechanism under fully loaded condition.
- 10.39.9.16 If it is advantageous to unload this way, the fully loaded boat can then be hoisted back by the crane and held in the embarkation position for unloading, followed by the transfer of the light boat to the davits for light boat release tests etc. as described below.
- 10.39.9.17 If it is advantageous to lighten the boat when waterborne, the weights can be unloaded from the boat, and the boat re-hooked to the falls (observing instructions in the release gear manual) and hoisted just clear of water and stopped for inspection (as in the manual). The light boat should then be released from this position by operation of the release mechanism to test it under the light load condition.
- 10.39.9.18 The light boat should then be re-hoisted some distance (with precautions and observations as in the manual), and lowered back into the water, and when fully waterborne tested for satisfactory off-load operation of the release gear.
- 10.39.9.19 (Repeat tests with the light boat (maintaining precautions and observations as in the manual) can be made as necessary to satisfy other requirements.)
- 10.39.9.20 The opportunity should also be taken to test the painter release mechanism when under load. (Note: The on-load release gear test should not be conducted without a proper purpose nor from a greater height than advised.)
- 10.39.9.21 The PIC at his discretion need not disconnect the crane but may allow it to remain connected but slackened. In such a case as the shipboard winch lowers the boat, the shore crane must correctly follow the boat movement during the brake test and thereafter down to the waterline when crewmen embarking the boat can disconnect the shore crane from the boat and then test the release mechanism at full load. (Note: While following this method it is also within the bounds of possibility that a sudden load may come on the crane due to failure of normal shipboard launching devices, and therefore minimum SWL of the crane is important).
- 10.39.9.22 If all the component items have been maintained in the prescribed manner and preliminary inspections of equipment's, logbooks, certificates etc. do not give any cause to doubt the adequacy of the equipment for the test, then at the discretion of the PIC the assistance of the additional crane may be waived, and the PIC may institute other means to enhance safety (e.g. the final 10 or 20% of the loading may take the form of suitable water bags or drums close to the boat entrances which may be filled by a hose from the ship. Some companies produce water bags

systems which can be laid out in empty condition and strapped to the boat to simulate full loading, and these bags can then be filled up from the shipside without the necessity to enter the boat).

- 10.39.9.23 Some older type lifeboats may not be fitted with on-load release gears. It is to be noted that the five yearly test is also required for such a boat and its launching appliance.
- 10.39.9.24 Lifeboats on vessels built before 1 January 1999 which are not attached to davits should be tested every five years by being attached to a device capable of putting the equipped boat and a crew of two in the water. If the device is not capable of putting the boat in the water with its complement of persons, then other suitable means shall be provided for embarking persons into the boat (see 10.38.8). Such devices are to be marked with a red band 150mm wide on a white background
- 10.39.9.25 Some individual shipowners in conjunction with lifeboat manufacturers and local MCA offices have devised alternative equivalent means for the load test which basically consist of:

10.39.9.26 With respect to the 5 yearly load test of lifeboats operators now have two options available to them:

Option 1

• Test the lifeboat, release mechanism and winch brake as a whole by testing the launching appliance, winch and brakes, lifeboat disengaging gears and lifeboat by loading the lifeboat to 1.1 times the total mass of the lifeboat when loaded to with its full complement of persons and equipment. The lifeboat shall then be turned out and lowered, during which the winch brake shall be operationally tested.

Option 2

- Test the lifeboat, release mechanism and winch brake as separate entities by
- A static load test of the lifeboat loaded to 1.1 times the total mass of the lifeboat when loaded with its full complement of persons and equipment.
- Using a hydraulic test device a load of 1.1 times the total mass of the lifeboat when loaded with its full complement of persons and equipment shall be applied to the release mechanism and the release mechanism shall be operationally tested under load.
- The lifeboat launching appliance shall be loaded (using a spreader bar) to 1.1 times the total mass of the lifeboat when loaded with its full complement of persons and equipment and the winch brake shall be operationally tested by lowering the weight and applying the brake."

10.<mark>39</mark>.9.<mark>27</mark>

If the release hooks are of the on-load type, if it was carried out above water, the boat can be lightened to 100% full load, and the release gear operated at fully loaded condition. If the test was done in a workshop, then when the light boat is resting on chocks on the workshop floor, hydraulic or mechanical jack loads can be set up between the hooks and the boat structure (provided the structure is strong enough for this purpose) and when the load on the hooks represent 100% fully loaded boat (this needs to be confirmed by hydraulic pressure or load cell), the central release gear can be operated to test simultaneous and satisfactory release at full load.

- 10.39.9.28 If the release hooks are of the on-load type and the 100% load release test cannot be carried out, the light boat is transferred to the ship and connected to its davits. The light boat is then lowered to the position just above water and held there for 100% loading to enable the fully loaded on-load release gear test to be performed.
- 10.39.9.29 Further tests with the light boat being handled by the shipboard davit are made to satisfy off-load release tests and other requirements.

10.39.10 LIFEBOAT AND RESCUE BOAT PAINTER RELEASE GEARS

10.39.10.1 The statutory requirements for painter release gears installed on lifeboats and rescue boats are contained in the LSA Code and Schedule 2, Part 1, paragraph 5.6 of MSN 1676(M).

DOCUMENT AMENDMENT HISTORY

Version Number	Status / Change	Date	Author Reviewer	Content Approver	Next Review Date/Expiry Date
01.21	Clarification of storage of lifejackets	19/01/21	D Fenner	G Stone	19/01/23
02.21	Update to Radar transponders section	19/01/21	l Platts/D Fenner	G Stone	19/01/23
	 Amended section numbering 				
09.21	Update references to MSN1872 Amendment No.2	31/08/21	D Fenner	G Stone	31/08/23