


<b>Lena Lighting / UV Cleanlight UV-C Sterilon 36w, 72w and 108w</b>	
<b>Aspect</b>	<b>Details</b>
<b>Images</b>	
<b>Alert Number</b>	2201-0375
<b>Product Type</b>	Electrical equipment - UV - C surface disinfection Lamp
<b>Product Identifiers</b>	Brand : Lena Lighting / UV Cleanlight Models : UV-C Sterilon 36w <u>without sensor</u> UV-C Sterilon 72w <u>without sensor</u> and UV-C Sterilon 108w models <u>without sensor</u>
<b>Product Description</b>	UV-C lamp advertised as effectively killing microorganisms, used for surface disinfection in a variety of healthcare and public settings.
<b>Country of Origin</b>	Poland
<b>Counterfeit</b>	No
<b>Risk Level</b>	Serious
<b>Risk Type</b>	Exposure to UV-C radiation resulting in damage to eyes and / or skin
<b>Risk Description</b>	<p>The product has been assessed as unsafe and presents a serious risk because there is a foreseeable risk of exposure to UV-C radiation, which could result in irreversible eye and/or skin injuries.</p> <p>The exposure limit value for this type of radiation is met within 3 seconds of energising the lamp and there are no safeguards in place, such as a motion sensor, to prevent exposure.</p> <p>The product does not meet the principal elements of the safety objectives set out in Schedule 1 (2) of the Electrical Equipment (Safety) Regulations 2016.</p>
<b>Corrective measures</b>	<p>We recommend end users stop using this product immediately.</p> <ul style="list-style-type: none"> <li>• The product was voluntarily withdrawn from the market in February 2021, until it could be brought into compliance.</li> <li>• The importer / distributor has been required to notify all existing end users of the risk.</li> </ul>

	<ul style="list-style-type: none"> <li>• The importer / distributor has been required to recall the non-compliant product from end users.</li> <li>• The importer has offered free of charge replacement with a compliant model, which features a motion sensor, to existing end users.</li> <li>• Any end user still in possession of a non-compliant model should ensure it is returned to the distributor from which it was purchased.</li> <li>• Contact the distributor you purchased from to request redress.</li> </ul>
<b>Online Marketplace</b>	N/A
<b>Notifier</b>	Health and Safety Executive