






Aqualung UK – Calypso Regulator with a specific CPN and serial number

Aspect	Details	
<p>Images</p>		
		
	 <p>Location of serial number</p>	
<p>Alert Number</p>	<p>PSD Case Number 2301-0171</p>	
<p>Product Type</p>	<p>Scuba Diving Regulator</p>	
<p>Product Identifiers</p>	<p>Common Part No (CPN)</p>	<p>Range of serial numbers</p>
	<p>RG126111</p>	<p>L077601-L077700</p>

The OPSS Product Safety Alerts, Reports and Recalls Site can be accessed at the following link: <https://www.gov.uk/guidance/product-recalls-and-alerts>



Product Recall

	RG126111	L084321-L084400
	RG126111	L085001-L085100
	RG126112	L077401-L077500
	RG126112	L085301-L085400
	RG126112	L076501-L076600
	RG126112	L076101-L076200
	RG126112	L077501-L077600
	RG126112	L083401-L083500
	RG126112	L082801-L082900
	RG126112	L082001-L082100
	RG126112	L083801-L083900
	RG126113	L077001-L077105
	RG126114	L080801-L080900
	RG126114	L085701-L085760
	RG126114	L076201-L076300
Product Description	The Calypso regulator controls the pressure of breathing gas for diving. It is connected to a gas cylinder containing oxygen compressed to a high pressure. The 1 st stage regulator reduces the pressurised breathing gas to ambient pressure every time divers inhale through the mouthpiece.	
Country of Origin	France	
Counterfeit	No	
Risk Type	Drowning/asphyxiation	
Risk Level	Serious	
Risk Description	<p>Regulators containing a potentially defective 1st stage body presents a serious risk of drowning. A variation in the manufacturing process of the 1st stage regulator has been identified, which results in a thinner wall section. An uncontrollable free flow of the 2nd stage could occur if this section ruptured under pressure, causing a catastrophic gas loss that may result in drowning.</p> <p>The manufacturing defect means the affected regulators may not supply the user with a breathable gaseous mixture and therefore do not meet the relevant essential health and safety requirements of Regulation (EU) 2016/425 on personal protective equipment.</p> <p>The issue only affects Calypso regulators with specific common part numbers (CPN) and serial numbers provided here.</p>	
Corrective measures	<p>Withdrawal of all affected products from the supply chain. Recall of all affected products still in service from end users.</p> <p>Any users in possession of a Calypso regulator with one of the CPNs or serial numbers listed here should stop using it immediately and contact their supplier for a free replacement.</p> <p>Details of the product recall can be found at https://uk.aqualung.com/en/recall-information/recall-information.html.</p>	
Online Marketplace	N/A	
Notifier	Health and Safety Executive	