M. RAUDING TRRORIST TIACKS

OFFICIAL

Supplementary Guidance – Physical Barriers to Delay and Discourage Attackers





Disclaimer

Reference to any specific commercial product, process or service by trade name, trademark, manufacturer, or otherwise, does not constitute or imply its endorsement, recommendation or favour by CPNI. The views and opinions of authors express, we this document shall not be used for advertising or product endorsement process.

To the fullest extent permitted by law, CPNI accepts no liability for any lo (whether direct, indirect or consequential, and including but not d to, of p or anticipated profits, loss of data, business or goodwill) incurred by and howsoever caused arising from or connected with any er or omission h cument or from any person acting, omitting to act or refraining f upon, or otherwise using You the information contained in this document or its reference nake your own judgment as regards use of this document and seek indep Jional advice on rotes your particular circumstances.

with

Contents

	itroduction	. 4
E	very barrier counts	. 5
E	very second counts	
Н	low barriers may be overcome	
С	choosing physical barriers	
L	ocking mechanisms	. 9
G	ilazing	12
D	loors	13
S	peedoates	15
R	evolving doors and portals	16
R	coller shutters and security arilles	17
Δ	ssuring security control rock perchant (they paty	18
^		20
A	nnexe A: Best practices for the sets and the ching mechanisms	20
A	nnexe B: Physical barrier beckh	21

- M&S M&S Food
- world food court Casino / Cinema / Bowling Restaurants

ET

INTRODUCTION

Intended audience

This document is intended for organisations in the public, private and third sectors. It is most useful for Physical Security Managers and Physical Security Advisers and Consultants.

Scope

Marauding Terrorist Attacks (MTAs) are fast-movine to a attacks where assailants move through a location uning to find and kill as many people as possible. Most withs occur within the first few minutes, before prove are a to respond.

This document is supplementary to a paurie fear the Attacks: Making your organisation reason uch discusses how your organisation can be agnise and the k, take immediate action and agnite the police.

Physical barriers in the doors, the eles and shutters and are not limited to device specifically signed for security.

The document out in location of has can delay of h Veration for spo

s how, and locked physical barrier ices, shapping centres and theatres ttackers and then discusses c types of barrier.

This docu.

ps organisations to:

- Assess how effectively their existing barriers are able to delay and discourage attackers
- Ensure existing barriers are configured to offer the longest delay possible
- Understand what to look for in relation to defending against marauding terrorist attacks when choosing new barriers.

Deploying and using states are criters is only one aspect of an organisation's defence a state marauding terrorist attack and must be blered in conjunction with other aspects of an organ attoms, and use. Refer to other documents in this guidance with

ument es not discuss:

CPNI's *Marauding Terrorist Attack Standard* VTAS, to be published Autumn 2020)

Vehicle barriers or other means of defending against a vehicle-based attack; see CPNI's guidance on *Hostile Vehicle Mitigation*

- Walls; see A Guide to Security Walling Systems for the Protection of Important Assets
- Active Delay Systems such as security fog; see Marauding Terrorist Attacks: Supplementary Guidance – Active Delay Systems
- Planning considerations for instigating lockdown using physical barriers; see *Marauding Terrorist Attacks: Supplementary Guidance – Lockdown*
- Planning considerations relevant to defending against the use of fire as a weapon
- Compliance with legal requirements such as fire safety, building standards and health and safety regulations, building standards; see *Marauding Terrorist Attacks: Supplementary Guidance – Lockdown*.



EVERY BARRIER COUNTS

view

The rapid pace of marauding terrorist attacks makes them particularly devastating, especially when the attackers are using firearms.

However, CPNI's research as well as analysis of previous attacks show that all barriers can reduce casualties by:

- Deterring an attacker from entering an area if they perceive a barrier as too difficult or time-consuming to overcome
- Delaying attackers' progress, giving potential mams more time to escape or hide
- Hiding potential victims from an attack
- Fatiguing and disheartening attackers
- Depleting an attacker's resources and damage knives, spend bullets or conate explored vices attempting to defeat a ser.



Figure 1: Attackers armed with assault rifle and explosives



EVERY SECOND COUNTS

Unobstructed, attackers can make rapid progress through an area, reaching many victims before they have become aware of the attack and taken action to escape or hide. Slowing that progress can be achieved without significant investment or specialist security equipment.

A barrier that takes 30 seconds to overcome is highly valuable. This means that even barriers that do not meet other security needs can make your site more resistant to a marauding terrorist attack.

Using multiple locked barriers means that the attention are delayed by each one they encounter, knowing with every second that passes, armed policities a significant to closer to arriving.

Figure 2: Closed roller shutter delaying progress of attackers







HOW BARRIERS MAY BE OVERCOME

Terrorists may overcome barriers using:

- Opportunism: exploiting doors left unlocked or that have been propped open
- Coercion: forcing someone to open a barrier
- Deception: impersonating people who are authorised to enter an area
- Force: breaking through a barrier using use their or bodyweight, their weapons, tools they have brow with them or items that are to hand, such as extinguishers
- Stolen keys or access control cards
- Activation of fire safety system at are to automatically disengage bocks

CPNI's analysis of ten and a string in the UK has shown that their attack planning is the to include detailed preparatik

The ability of charge is to vercome physical barriers in the dependent their sophistication as well as the properties whe barrier itself. The skills, tools and wear uts likely to be used by terrorists of different levels of the transmission of the figure below. If threat varies between organisations and also between a upont sites.

Attackers armed with guns or explosives may be reluctant to use limited supplies of ammunition and charges to overcome barriers, instead intending to use them to kill people during the attack.



Figure 3: Skills, tools and weapons likely to be used by terrorists of different levels of sophistication

OFFICIAL 7



CHOOSING PHYSICAL BARRIER

Discouraging and delaying an attacker from entering an area is typically the primary aim of a barrier in the event of a marauding terrorist attack. The ability to stop bullets, which is much more difficult and costly to achieve, is not usually required since stopping the attacker at a barrier allows personnel and members of the public to move out of sight or out of range.

Understand what a barrier needs to achieve in response to all security risks including crime prevention. Barriers specifically designed for security are likely to provide protection but can be expensive and may not be nactical for many sites. Modifying existing barriers can be effective and cost-efficient approach. Prioritise barriers that the barriers at ackers' entry to likely target areas to maximise the personnel and members of the put the pape or hide. These are often barriers at points of entry of the put the points of entry of the person of the

offers is determined by a combination lay a b sign, it. aterials and manufacture, its locking of its they are configured and how the door meg hisms, ho ations in these make it difficult to predict ctly how long it would take to defeat a particular barrier ed in a particular place. However, CPNI's research has own that some designs, materials, locks and configurations consistently offer better resistance to forcible attack. The following sections of the document discuss locks and glazing, aspects relevant to all types of barrier, before discussing these factors for specific types of barrier.

LOCKING MECHANISMS

the

The delay to forcible attack offered by a physical barrier is only relevant if that barrier is locked at the time of the attack. Barriers that are open or unlocked when an attack begins must be quickly closed and secured. This means that locking mechanisms need to be simple and fast to operate as well as being strong enough to resist entry by force.

Locking barriers safely

Ensure the safety of the person using the lock.

Remote activation of a lock is ideal to minir exposure of the person locking it. With electroperated locks this could be achieved by:

- Using a centralised locking
- Providing a wireless representation control or provident button so that the lock can be end whilst the operator escapes

ste

anism controls away from the Installing I ng barrier on th de (the side to which the oteci bar ess b attacker); for example, cks tter to be closed from behind a allo than requiring someone to stand ecer ing down a button. nce ho.

Locking his to be controls should be positioned to allow the operator to maintain awareness of the situation; for example, locating the control at chest height rather than forcing the operator to stretch up or crouch down.

Make locking revers.

FIRE

RXI

Circumstant, may change coup the attack, for example if there we with a way be essential to reopen a locked barrier to also performed members of the public to enope. Key would locks are undesirable since the committee the area or been killed.

The control of the co

Ensuring emergency services can unlock the barrier

The swift action of the police, fire brigade and ambulance will be required to save the lives of those in the area. Plan how emergency services would be able to reopen a locked barrier, for example through remote unlocking by security control room operators or provision of a grab bag containing keys or access control passes on their arrival.

Locking barriers quickly and easily

Ensure the person operating a lock can escape or hide as soon as possible. The person operating the lock is likely to be under severe stress and therefore the locking mechanism should be straightforward to operate. This means:

- Minimising the number of steps, clicks or keypresses to fully engage the lock
- Minimising the number of pieces of equipment, such as keys or bars to be located
- Avoiding locks that require manual dexterity at a time when the person's hands may be shaking, such as inserting a key or card into a narrow opening.

R TO

Exi

Latch bolts allow barriers to be locked as they are closed. Use latch bolts that are described as a "dead latch" or which have "deadlocking" or "anti-thrust" security features since these are typically more difficult to manipulate open.

Figure 4: Enoperation via thumb-turn that needs little two is prated by single, reversible action and reversible actional equipment

Resisting forcible attack

A barrier is only as strong as its weakest point, which includes the locking mechanism.

Type of mechanism

Locking mechanisms using bolts can significantly delay attackers. Bolts should protrude a minimum of 17mm into the keep. Dead bolts offer greater resistance to an attacker than latch bolts, though the latter may be preferable for rapid operation.

For electrically operated locks, this includes:

- electromechanical solenoid locks (dead bolts)
- motorised locks (dead bolts)

Inter

double

locks

eaf hardwood timber fire doorset

electronic strikes with mechanical locks (latch bolts).

Maglocks with a strong holding force (typically 24V models) can also offer a significant delay on outward opening doors, though are not suitable for use with ve flexible materials such as glass.

Multiple locking points

Resistance to forcible attack is increased by using multiple locking points as the force of any impact is distributed across the points rather than focussed on one.

This can be achieved by using a lock with pultiple bolts, multiple maglock holding points or non-le separate locks.

Centrally located lock for s

ed

nechanisms

the (Locating a lock cent of a ning ec eight rather than barrier (for a door, this the top or bott s mo tack since it sista he barner in an attempt to makes it more di sm. This is particularly disengage the locking impor arriers made very flexible material such a

-pd

rface i

Notifing looping hardware on the protected surface the set the greatest resistance to ballistic attack as well as manual attacks on the lock mechanism, ince it receives the protection of the full thickness of doorset.

Hidden control boxes and cables for electrically operated locks

For most electrically operated locks, cutting the power releases the mechanism. Even a low sophistication attacker may attempt to damage a control box or cut exposed cables. Hide control boxes and cables where possible.

GLAZING

Reducing an attacker's visibility

Glazed façades, glazed doors, glazed walls and door vision panels can allow attackers to see potential victims within an area. Frosted glass (also called privacy glass or opaque glass) is preferable since it blocks attackers' line of sight whilst allowing much of the light to pass through. Frosted films can be retrofitted to existing glass to achieve the same effect.



Choosing glazing to delay attackers



delaj attack a dr. je glazed

polycarbonate will provide the greatest is more effective as the inner pane of mit than as a single layer.

by pass (also called float glass), often found in older by pass, provides very little resistance to forcible attack. Toughened glass (also called tempered glass and safety glass) is slightly stronger but still offers minimal delay to an attacker using force.

Where it is not practical to replace annealed or toughened glass, their resistance to forcible attack can be improved by fitting anti-shatter film. This holds the fragments in place when the glass breaks, which also reduces the risk to personnel and members of the public from flying glass fragments if an explosive device is detonated. Extending the film into the glazing retention system is much more effective than the more rapid method of installation where the film is installed only to the edge of the vision panel (termed "daylight filming").

Ensure that the glazing material and any films applied to it are suitable if fire protection is required.

DOORS

Choosing new doors

CPNI's research has shown that the following types of fire doorset (the door and frame), fitted with a suitable locking mechanism, are highly capable of delaying attackers:

- Hardwood timber
- Hardwood timber augmented with steel inserts in the leaves or frame
- Steel.

Even though bullets can pass through these types doorset, they are unlikely to open when she to quiring an attacker to use their bodyweight or tools to the entry. Steel constructed or augmented doorsets can be main shut when attacked with explosives.

Where a higher risk justifierent higher cost, courity doors tested to CPNI's standare proves a greater way and resistance to bullets and explosion. Consult your local police force Counter provism Sector Adviser (CTSA) for more details Glazed domain and ly offer a shorter delay than doors made of other mats. The lazing flexes significantly when impact when can bause locking mechanisms in ngage. The resistance to forcible attack can be maximed by:

sing under door (typically a steel frame with a single glass panel), which is much less flexible than unframed glass door

Using glazing that is resistant to forcible attack *(see the Glazing section)*

Using a locking mechanism that is resilient to distortion of the door, such as a bolt installed halfway up the door (see the Resisting forcible attack section in Locking Mechanisms)

Improving existing doors

There are relatively low-cost options for retrofitting existing doors to significantly improve the delay they offer in the event of an attack.

Adding door bolts

Door bolts, operated by a thumb-turn or key, can be retrofitted to most doors. Thumb-turns mean that no time is wasted looking for keys during an attack, making them ideal for areas where personnel and members of the public may seek shelter, such as a meeting room or a shop back-room.

Using supplementary locking devices

Supplementary locking devices are commercially available that are designed to make hinged doors more difficult to open. These require rapid manual fitting in the event of an attack, with the parts stored next to the door.

CPNI has tested a range of devices and a should their performance to be variable. The *Nightlock artiginal* and *Nightlock Lockdown 2* devices a should be single-leaf doors, were found to performed to when tested on double-leaf doors, found in a by office period.



re 9: ERA Lockdown for double-leaf doors

Many other devices, often marketed for use in hotel rooms, do not to offer any significant delay. Worse, these devices along with door chains or wedges can show an attacker that a room is occupied, encouraging them to force entry where they may have otherwise moved on.

Barricading using furniture

Furniture can be used to barricade a door effectively, though doing so risks alerting attackers that the room is occupied and attracting them by generating noise. Personnel should be trained that to be most effective, rigid pieces of furniture should be placed behind an inward opening door, filling the space to the opposite wall or something else structural such as a pillar.



Figure 10: Using furniture to barricade a door





Figure 8: Thumb-turn operated secondary door bolt fitted to an external door constructed with framed glazing

fitted

C

SPEEDGATES

Many designs of speedgate, often used at the entrances of large office buildings, offer negligible delay. It can be easy to climb over, pass underneath or even push through many designs of speedgate. When choosing speedgates look for the following features:

- Leaves at least 1.8m high above floor level
- 220mm gap or less from the floor to the bottom of the leaves
- Sloping plinths (where people would typically ge passes) that cannot easily be used as a stern climb the barriers
- Fixed panels of a similar height to the leave above the plinths so that attackers cannot easily between the sets of leaves
- For transparent leaves, ..., g lamina, slazing or polycarbonate to reader more diffice break.

Figure 11: Speedgate design that will delay attackers



Figure 12: Speedgate design offering negligible delay

REVOLVING DOORS AND PORTALS

Revolving doors can significantly delay attackers, even those using firearms. Revolving doors should:

- Be fitted with laminated glazing or polycarbonate (see the Glazing section)
- *Ideally have four leaves rather than three, since CPNI's research indicates the former design is more resistant to forcible attack
- *Be lockable in a position where all the segment are open in order to prevent use of explosive a closed segment.

Many designs of revolving door are difficult above to and lock. Consider whether it may be possible are retroft existing doors with mechanisms that are in line to be principles described in the section.



Figure 13: Four-leaf revolving door positioned with all segments open

Portals (often called to, and so so offer a significant delay, since their closign means to an utacker must effectively defeat two and they are typically constructed using laminated goods, we construct a barrier even when shot.

ante per sonten la code personnel to enter a code before ante per la la code personnel to enter a code before leave eople extracted. Designs that allow a person to enter of person to e



Figure 14: Portals

ROLLER SHUTTERS AND SECURITY GRILLES

WE STILL GOT

Roller shutters or security grilles (collapsible or extendable), often used for shop fronts and loading bays, will significantly delay the progress of attackers, even those with firearms and explosives. Locating controls for the shutter inside the protected area and away from the shutter itself reduces the risk to a person operating the closing mechanism in the event of an attack.





ASSURING SECURITY CONTROL ROOM OPERATORS OF THEIR A SIT

The actions of security control room operators (where sites have them) are crucial when responding to a marauding terrorist attack.

Historically, terrorists have not sought to gain access to security control rooms. However, personnel within that room should feel safe and confident that they will be protected whilst working to protect others. For this reason, security control rooms should be constructed to offer resistance to forcible attack. CPNI provides guidance on security wall systems and security doors. Sound-proofing a securcontrol room and preventing smoke ingress can be the operators focus on dealing with the incident.

Security control room operators may need to be the deformed to be the



Figure 16: Policeman identified using external CCTV camera

Further information

You may find it useful to use this document alongside other CPNI documents:

- Marauding Terrorist Attacks: Supplementary Guidance – Lockdown
- A Guide to Security Doorsets and Associated Locking Hardware
- A Guide to Security Walling Systems for the Protection of Important Assets
- Control Rooms Guidance
- A suite of documents relating to *Windows* and *Glazed Façades*.

For information tailored to your organisation, contact your local police force CTSA.

© Crown Copyright 2020

ANNEXE A: BEST PRACTICES FOR DOORSETS AND LOCKING MECHANISMS

Variations in design, manufacture, materials, locking mechanism and configuration make it difficult to predict exactly how long it would take to defeat a particular door installed in a particular place. However, CPNI's research has shown that some designs, materials, locks and configurations consistently offer a better resistance to forcible attack. An overview of best-prach, phoices for doorsets (door and its frame) and locking methods is shown in the figure below.



OFFICIAL

ANNEXE B: PHYSICAL BARRIERS CHECKLIST

This annexe to CPNI's document *Marauding Terrorist Attack: Supplementary Guidance Physical Barriers to Delay and Discourage Attackers* provides a checklist of best-practices for locking mechanisms fitted to barriers as well as for the construction and design of several types of barrier.



